



## SIDE BARRIERS PRO-SERIES

### Assembly Instructions

The information in this document is subject to change without notice.

© Copyright The Net Return™  
2007, 2018. All rights reserved.

750101




Read all the warnings before you assemble and use the sports net.



Be sure that you orient your net properly. The Net Return logo always faces the athlete.



Avoid exposing your net to prolonged ultraviolet light as this may fade and/or degrade the sleeve fabric. When not in use, move to a shaded area.




Maintain a safe clearance around and above your net. When orienting your net, consider the surrounding area. Athletes are responsible for injury or damaged caused by a mishit ball.



Do not hang, kick, cut or climb on your net. Avoid contacting the net with any sporting equipment other than a ball.



Danger of tipping over! Always weight base with sandbags.




- Lay out the 2 side barriers and 4 sand bags as shown.

**NOTE:** Throughout this manual, certain images contain parts that have been colored yellow. This is meant to bring specific attention to a specific step and is not a representation of their actual color.




**Scan the code** for a helpful demonstration video or visit [www.thenetreturn.com](http://www.thenetreturn.com) for more details.

2





- First, locate the side barrier with the **Red** Velcro strap and align it to the right side of your Home Series Net.
  - Feed the Velcro strap around the frame section and fasten securely.
  - Then, fasten the Velcro strip along the edge of your side barrier to the corresponding Velcro strip on your net.
  - Repeat the same process starting with the **Blue** Velcro strap on the second side barrier.
- TIP:** If it is easier, gently lay your Home Series Net on it's back to complete this step.

3



- Stand your Pro Series Net up.
- Locate the lower Velcro straps on the side barriers. Fasten these securely around the base of the frame.

4



- Fill each of your sandbags with approximately 15 lbs (7 kg) of sand.
- Locate the remaining Velcro on the side barriers. Fasten these securely through the handle of your sandbags.
- Extend the sand bag out to the desired distance. You can flare them wide or they can go straight back.
- You have successfully installed the Side Barriers.