



## SIDE BARRIERS V2

### Assembly Instructions

The information in this document is subject to change without notice.  
© Copyright The Net Return™ 2007, 2021. All rights reserved.

750204



Read all the warnings before you assemble and use the sports net.



Be sure that you orient your net properly. The Net Return logo always faces the athlete.



Avoid exposing your net to prolonged ultraviolet light as this may fade and/or degrade the sleeve fabric. When not in use, move to a shaded area.




Maintain a safe clearance around and above your net. When orienting your net, consider the surrounding area. Athletes are responsible for injury or damage caused by a mis-hit ball.



Do not hang, kick, cut or climb on your net. Avoid contacting the net with any sporting equipment other than a ball.




Danger of tipping over! Always weight base with sandbags.




- Lay out the 2 side barriers and 4 sand bags as shown.

**NOTE:** Throughout this manual, certain images contain parts that have been colored yellow. This is meant to bring specific attention to a specific step and is not a representation of their actual color.





1





2

- To attach the side barriers, select one side barrier and align it to one side of your net.
- Fasten the Velcro strap (highlighted in yellow) around the top frame section and fasten securely as shown in the first box above.
- Then, fasten the Velcro strip (also highlighted yellow) along the edge of your side barrier to the corresponding Velcro strip on your net as per the second box above.
- Repeat the same process for the other side barrier.



- Locate the lower Velcro straps on the side barriers. Fasten these securely through the net near the base of the frame.



- Fill each of your sandbags with approximately 15 lbs (7 kg) of sand.
- Locate the remaining Velcro on the side barriers. Fasten these securely through the handle of your sandbags.
- Extend the sand bag out to the desired distance. You can flare them wide or they can go straight back.
- Congratulations, you have successfully installed the Side Barriers.