

# EASISOLV 120

# **ON PRESS CLEANER**

EasiSolv 120 On Press Cleaner is designed to remove all inks from the screen printing mesh. This product evaporates quickly and should not be rinsed with water. 120 is to be used during on press color changes, saved screens, removing ink from squeegees, floodbars and other equipment.

# SPECIAL FEATURES:

- EasiSolv 120 effectively dissolves most inks, including: conventional/solvent, electronic, solder mask, UV, plastisol, water base and pad inks.
- EasiSolv 120 will evaporate quickly and without leaving a residue which makes tape applications very simple and lasting.
- EasiSolv 120 may be applied manually or recirculated through the EasiFlo™ System, or in an enclosed, automatic screen washing system, providing superior product life and economy.

# APPLICATION FOR USE:

- Scrape all excess ink from screen.
- Apply EasiSolv 120 by squirt bottle, pneumatic sprayer or by rag to the ink side of the screen.
- Thoroughly agitate ink with a rag or scrubber, then wipe up all dissolved ink.
- Reapply if necessary and follow with a dry rag, wipe on both sides of the screen.
- The screen will be ready for printing or tape application within 20 seconds.

# PHYSICAL AND CHEMICAL DATA:

#### Appearance & Odor:

Clear liquid with ether-like odor

#### **Specific Gravity:**

 $0.95 @ 20^{\circ} C / 68^{\circ} F$ 

#### pH:

Neutral

# VOC:

950 grams/liter

### Flash Point:

48  $^{\circ}$  C / 118  $^{\circ}$  F

# **Ink Types:**

Plastisol

U٧

Conventional/Solvent

Electronic

Solder Mask

Water base

Pad Inks

#### **Product Family:**

Textile

Graphic