

wick to wax buying guide

wax details

wick pairings

waxes	fragrance load	melt point	pouring temperature	cure time	ultimate	quiet	shaped
<u>virgin coconut soy™</u>	9-10% but can easily handle up to 12%	122° F (50° C)	80°-190° F (82°-88° C)	72 hours	Ultimate Wick .03	Whisper Booster Wick .03	Spiral Wick .01
<u>coco apricot creme™</u>	9-10% but can easily handle up to 12%	129° F (55° C)	80°-190° F (82°-88° C)	72 hours	Ultimate Wick .02	Whisper Booster Wick .02	Tube Wick .01
<u>deluxe satin soy™</u>	9-10% but can easily handle up to 12%	122° F (50° C)	80°-190° F (82°-88° C)	72 hours	Ultimate Wick .03	Whisper Booster Wick .03	Spiral Wick .01
<u>hemp coco soy™</u>	9-10% but can easily handle up to 12%	120° F (49° C)	150°-160° F (65°-7° C)	72 hours	Ultimate Wick .03	Whisper Booster Wick .03	Spiral Wick .01
<u>beeswax coco creme™</u>	9-10% but can easily handle up to 12%	137° F (58° C)	150° F (65° C)	72 hours	Ultimate Wick .03	Whisper Booster Wick .03	Spiral Wick .01
<u>pure palm paraffin™</u>	10%, testing required	138.4° F (59° C)	150-160° F (65-71° C)	24-48 hours	Ultimate Wick .02	Whisper Booster Wick .02	Tube Wick .01
<u>supernatural soy flakes™</u>	9-10% but can easily handle up to 12%	122° F (50° C)	140-150° F (60-65° C)	72 hours	Ultimate Wick .04	Whisper Booster Wick .03	Spiral Wick .01
<u>cocoglo soy™</u>	9-10% but can easily handle up to 12%	110° F (43° C)	140-150° F (60-65° C)	24 hours	Ultimate Wick .02	Whisper Booster Wick .02	Tube Wick .01"
<u>supreme parasoy™ pillar wax</u>	10%, testing required	140° F (62.7° C)	160-200° F (71-93° C) testing required	72 hours	Crackling Single Ply .02	Whisper Single Ply .02	N/A
<u>ultracreme paraffin™ pillar wax</u>	10%, testing required	135-140° F (57.2-60° C)	160-200° F (71-93° C) testing required	72 hours	Crackling Single Ply .02	Whisper Single Ply .02	N/A