


DESKY

Computer Monitor Light Instructions



BOX CONTENTS



- ① Bracket
- ② Monitor Light Bar
- ③ ON/OFF touch switch, Dimmness adjustment
- ④ Step/ Seamless color adjustment touch switch
- ⑤ Type-C USB slot
- ⑥ RGB backlight

PRODUCT SPECIFICATIONS

Voltage: 5VDC. 2A

Power: Max.8W

Power Source Wire: TypeC-USB

Light Source: 2835LEDs+5050RGB (Ra>90)

Color Adjustment: 2700~6500K stepless/step adjustment

Brightness: 10%~100% stepless/ step adjustment

Illumination: Max.700Lux@50cm

Lighting Area: 31.5*23.5in@19.5in.
(80*60cm@50cm.)

Lens: Milky PC cover + PMMA Fresnel lens

Size: 16.5 in (42cm) length

ABOUT THIS DEVICE


RGB key on the left of the lamp body: short press the execution sequence: turn on the backlight, breathing lamp, music mode 1, music mode 2, and turn off. Long press to execute music mode 1.

Right button of lamp body: short press to switch the front lamp and switch the third gear color temperature, long press to adjust the brightness by 10% - 100%.




INSTALLATION

STEP 1: Connect the included type C USB cable to the bracket.



STEP 2: Place the bracket on top of your monitor or laptop. Ensure that the bracket is stable. The bracket is retractable so it will hold onto the monitor. The silicone surface won't damage the monitor surface.



STEP 3: Attach the monitor light bar to the bracket. The lens should face downwards and may be rotated based on preference height of the user to avoid glare.



STEP 4: Connect the other end of the USB cable to the USB port.



SWITCHING ON/ OFF & DIMNESS ADJUSTMENT


1. Gently touch right end cap once to switch the light on. Touch again to adjust dimness (stepped) and switch off.



2. Long press the right end cap to seamlessly adjust dimness.

COLOR ADJUSTMENT

1. Tap the left end cover to select three different RGB colorful change modes. From opening to color cycle to sound control



2. The sound sense function is the soundsense of light off and constant light on

MAINTENANCE

1. Please ensure that the light bar is securely fastened to the bracket using the magnet. If there is play, it may not be fastened properly.
2. This product is not waterproof.
3. This product can be used by children only under adult supervision.
4. Glare may cause eye fatigue if used for a prolonged period. Adjust dimness and take frequent breaks to avoid eye fatigue.
5. The device shall only be cleaned with a dry cloth.

FAQ

1. Monitor light does not switch on. Ensure that the USB cable is connected and light is securely attached to the magnetic pins in the bracket.
2. There is too much glare. Ensure brightness and color is adjusted appropriately. Ensure that the light is rotated away from the eyes. Only illuminate the keyboard area. If eye fatigue persists, discontinue use.
3. During video calls, the recipient cannot see me or my video is too bright. Ensure that the light bracket does not cover the camera (for laptops). Adjust brightness so that the recipient can view well.