



DESKY

○
DESKY

Pro Ergonomic Chair

Instruction Manual



Material Description




1. Upholstery / 3D Mesh
2. Armrest / PU Inner Board
3. Backrest / PA+35%GF
4. Seat / PP+30%GF Moulded Foam
5. Mechanism / Steel
6. Gas-lift / Steel
7. Base / 360mm Aluminum Alloy
8. Caster / Back PU



Coral




Black



White




Installation








Step 1

Step 2



Step 3

A	x1	B	x4	C	x4
					
M5		M8*35		M8*20	

H	x4	I	x4
			
∅ 8.5 ∅ 17 T2		∅ 8.5 ∅ 14 T2.5	

Function



Height	975 - 1060mm
Seat depth	450 - 510mm
Seat width	500mm
Seat height	440 - 525mm
Backrest width	430mm
Distance from seat to the top of backrest	520mm
Width between armrest	490mm
Distance from floor to armrest	625mm
From seat to armrest	195 - 255mm
Tilt angle degree	105° ~ 125°

1 Lumbar Support / At the back of the chair



Pull up or down the lumbar support by both hand at the same time

Lumbar support may result in relief of lower back pain especially in a long working hour.

2 Adjustable Armrest / Height adjustment



Pull up to increase height, vice versa pull down to lower height when highest point reached.

Armrest can reduce tiredness to arms and shoulders.

3 Sliding Seat / Function lever located on the left hand side of mechanism



Pull out function key for sliding function

Adjust Sliding seat so that hips and knees are at a 90 degrees angle, it reduces tiredness.



5 Tension Tilt / Control rod on the right hand side of mechanism



Twist outward to release tension



Twist inward to increase tension

Tension tilt offers more secure and comfortable working environment.

4 Height Adjustment / Control rod on the right hand side of mechanism



To lower seat, place your full weight on the chair, and engage actuator lever. When the desired height is reached, release the actuator.

To raise the seat, shift your weight to your feet. Engage actuator. Chair will rise automatically


Position chair so your feet are flat on the floor, and lower legs are at a 90-degree angle (or better) relative to your upper legs.

6 Three Positions Tilt Lock / Control rod on the left handside side of mechanism



Pull out the control rod to unlock tilt function and adjust, relock control rod when desired angle reached

Tilt lock allows the user to sit in an upright position for keyboarding, while providing a comfortable rocking/reclining motion during work or break.



DESKY

DESKY