



FREESTANDING BATHTUB INSTALLATION GUIDE

WARNING: Do not install this product without a complete inspection in case of rough handling along the shipping route or at the job site. Inspect the tub thoroughly upon arrival. Make sure every part of the tub is free of damage before installation. If there is any problem with the bathtub or piping system during the pre-installation inspection and water test, do not install the unit and contact Eisen immediately. All pre-installed units must be checked and retightened carefully before installation.




(pic1)




(pic2)

PREPARATION


1. Clean the floor and prepare as flat a surface as possible before installation.
2. Place the unit on the floor in the designated installation area. Mark the outline of the bathtub with a pencil or pen (pic 1).
3. Measure the drain and waste location under the unit, and determine the correct position of the drain pipe (pic 2).
4. Cover the unit with a blanket, cardboard, or other clean, protective materials so the unit is well protected during the drain installation process.
5. Pop-up drain is pre-installed in the bathtub.



(pic3)



(pic4)



(pic5)

6. Attach the rubber drainer gasket to drain body first; set the connector to drain body; connect waste pipe to connector and tighten; do not overtighten (pic 3).
7. Insert waste pipe into waste location.
8. Apply ample adhesive or silicone to the bottom of the supports (pic 4).
9. Apply ample amounts of tile caulk around the edge of the base.
10. Set the tub into the position correctly by connecting it with the previously installed drain hardware.
11. Fill the tub with water to the overflow drain for a minimum of 24 hours, then drain the tub to inspect for water leakage.
12. Once the bathtub is in place, wipe off any excess tile caulk and adhesive where the tub meets the floor. Strip away any excess caulk with a wet cloth (pic 5).