

Calculator for cornice, pelmet and plinth

Enter the sizes of your cornice, pelmet and plinth into the tables below. Add together the individual lengths and multiply the total measurement by 1.2 to give you an amount for cuts and wastage. Divide this number by the actual length that the actual cornice, pelmet or plinth you have chosen is supplied in. **Watch Video**

*If you don't want to have any joins on your Cornice, Pelmet or Plinths, please make sure you allow for your longest lengths to be accommodated. You will have to allow for more waste in your cutting process. This can only be calculated by measuring your longest lengths and cutting accordingly.

[Watch Video](#)

Example

Cornice

EXAMPLE total measured length = **6804mm**
 Multiply by 1.2 (to allow for waste) = **8164.8mm**
 Divide by supplied length = **8164.8mm** divided by 3000mm (Length Supplied) = **2.7216**
 Lengths actually needed = **3**

CORNICE total measured length =
 Multiply by 1.2 =
 Divide by supplied length = divided by (Length Supplied) =
 Lengths actually needed =

PIINTH total measured length =
 Multiply by 1.2 =
 Divide by supplied length = divided by (Length Supplied) =
 Lengths actually needed =

PELMET total measured length =
 Multiply by 1.2 =
 Divide by supplied length = divided by (Length Supplied) =
 Lengths actually needed =

Lengths of CORNICE Needed =
Lengths of PLITH Needed =
Lengths of PELMET Needed =