MICRO INVERTER



USER MANUAL

..... Green Energy Expert.....


IoT Monitoring Platform

Smart mobile "core" life

- CO-2 induced environmental analysis
- Daily and total energy generation in kWh
- Actual DC input voltage, current and power
- Actual AC output voltage, current and power
- Inverter temperature
- Historical (daily, weekly, monthly) power curve
- Power losses due to weather induced effects
- Optional limitation of power output
- Online switch for the inverter start stop







- CO-2 induced environmental analysis
- Daily and total energy generation in kWh
- A Actual DC input voltage, current and power
- (v) Actual AC output voltage, current and power
- Inverter temperature

Accessories

- Optional limitation of power output
- Online switch for the inverter start stop
- Historical (daily, weekly, monthly) power curve

ACOPOWER Micro inverter Use Manual(Life)

ACOPOWER* Micro inverter Use Manual(Life)

model	WVC-350		
Recommend use panels	1*435Watt		
Output voltage mode	120/230V Auto switch		
PV Open circuit voltage	33-60VDC		
Operating voltage range	22-60V		
Starting voltage range	22-60V		
short-circuit current	18A		
Maximum working current	16A		
Output parameters	@120V	@230V	
Output peak power	350Watt	350Watt	
Rated output power	330Watt	330Watt	
Output current	2.91A	1.52A	
AC voltage range	85-160VAC	180-265VAC	
AC frequency range	48-51Hz/58-61Hz	48-51Hz/58-61Hz	
Power factor	>95%	>95%	
Number of branch connections.	15PCS (Single)	25PCS (Single)	
Output efficiency	@120V	@230V	
Static MPPT efficiency	99.5%	99.5%	
Max output efficiency	95%	95%	
Loss of power at night	<0.5W	<0.5W	
Total current harmonics	<5%	<5%	
Appearance and technical features			
T	200C to 1500C		

1.1		
Temperature range	-20°C to +50°C	
Size (L×W×H)	165mm×176mm×38mm	
Net amount	0.82kg	
Waterproof grade	Ip65 NEMA3R	
Heat dissipation mode	Self-cooling	
Communication mode	Wi-Fi	
Power transmission mode	Reverse transmission,Load priority	
monitoring system	APP	
Electromagnetic Detection	EN61000-6-1:2007 EN6100-6-3:2007+A1:2011+AC:2012	
Power Grid standard	EN50549-1、EN 50549-2、NBR 16149:2013、UL1741	
Power grid detection	IEC/EN 62109-1、IEC/EN 62109-2、IEC 62116、IEEE 1547	
Certificate	CE, CEC, ETL	

Packing weight


r deking weight			
Specifications	Each (Packing)	Box (15PCS)	
weight	1.05 K G	16.2 K G	
Size	245×202×60mm	450×395×345mm	

Detailed




System diagram

Exterior



With N wire connection (Single phase 120/230V)



1-L1-Live wire 2-G-Ground ■ •---- G-yellow & green

No N wire connection(Single phase 120V)

•••••• N-blue 0.75mm² L-brown

Use this AC bus as the AC bus for each branch. Connect it hand in hand to form a modular micro-inverter branch wiring system.

Note: You can purchase a professionally customized AC bus with a T-type connector.

When the inverter is not started/shutdown and has been connected to the grid, the status of the LED indicators is as follows

1) When the inverter is not working ------ Red light is always on 2) When the inverter is in working state ----- Blue light flashes (MPPT is locked to a long light state)

When the inverter is not started/shutdown and is not connected to the grid, the LED indicator status is as follows

1) When the inverter is not working ----- Red light flashes 2) When the inverter is in working state ------ Blue light flashes (MPPT is locked in a long light state), and the red light flashes once every three seconds



DOWNLOAD Cloud Intelligence APP

Please use the QR code to scan and install the "Cloud Intelligence" client application, System version: Android 5.0, IOS 9 and above









Note


Please strictly observe the following installation conditions

- a) Connect the communication antenna on the inverter;
- b) Install the inverter in a place where the Wifi signal is well covered;
- c) The connected Wi-Fi network needs to be in 2.4G communication mode;
- d) If the WiFi signal cannot effectively cover the inverter, an additional WiFi signal booster can be installed;
- e) Turn on the Bluetooth of the mobile phone;



Features

Smart APP can realize real-time data transmission with the cooperation of Alibaba Cloud IoTThrough graphs and graphic displays in time, users can understand the operation of the power station. The user can monitor the operation and adjust the output power function of the system.



Cloud Intelligence APP



INTELLIGENT lot MONITORING MODEM Number of data collectors per Modem **Built-in WiFi IoT data terminal** Can be used on any smart device (Android/iOS)

- CO-2 induced environmental analysis
- Daily and total energy generation in kWh
- Actual DC input voltage, current and power
- Actual AC output voltage, current and power • Inverter temperature
- Historical (daily, weekly, monthly) power curve
- Power losses due to weather induced effects
- Optional limitation of power output
- Online switch for the inverter start stop

ACOPOWER

Micro inverter Use Manual(Life)

Micro inverter Use Manual(Life)

☼)) Bluetooth Mode

Setp 1


Setp 3

Turn on the Bluetooth of the mobile phone, click the "+" icon to add the device;



Setp 2

When the inverter appears on the automatic discovery page, click the "+" sign




Setp 4

The system will enter the network configuration state



Select WiFi signal, enter the

Wi-Fi password; click Next



🗟 Wi-Fi Mode


Setp 1

Bluetooth distribution network fails, you can click to scan the QR code to operate



Setp 2

Scan the QR code on the inverter to activate network operation



Setp 3

Select WiFi signal, enter the Wi-Fi password; click Next

Setp 4

The system will enter the network configuration state

