


## HELMET SCRIM INSTALLATION MANUAL









1. Turn over the helmet scrim so that the "sticky/ shiny" side faces you

2. Feed the bungee cord through all of the slits, starting from the front of the helmet scrim (flat side). Make sure to distribute the length evenly on both sides



















## 13. Pull the helmet scrim to the back until it covers the surface of helmet







## Installation completed



