



USER MANUAL SP-FR SERIESA

go to our web
www.tigerkingsafe-us.com
click [chat with us](#) to have live
chat

Email: Support@tigerkingsafe.com

Facebook: [@TIGERKINGSAFES](#)

Messenger: m.me/TIGERKINGSAFES

Version: V202307



HOME SAFE

MANUAL

01 STRUCTURE

02 FIRST OPENING INSTALL BATTERIES

03 SET UP THE CODE

04 FINGERPRINT SETTING

05 OPEN THE DOOR DUAL AUTHENTICATION SETTING CLOSE THE SAFE

06 DUAL ALARM SYSTEM SILENCE MODE LOW BATTERY

07 CUSTOMER SUPPORT & WARRANTY

⚠ WARNING

PLEASE DO NOT MOVE THE SAFE WHILE THE DOOR IS OPEN.
PLEASE DO CLOSE THE DOOR BEFORE MOVING THE SAFE.

Tigerking safe recommends that you do not store loaded guns in this unit.

If you experience any problems or challenges with your safe, please feel free to contact us for quick response. Many issues can be resolved promptly without the product needing to be returned.

Our customer support team is always available to answer any questions and help to resolve all concerns you may have.

Email: Support@tigerkingsafe.com



Facebook: [@TIGERKINGSAFES](https://www.facebook.com/TIGERKINGSAFES)

Messenger: [m.me/TIGERKINGSAFES](https://www.m.me/TIGERKINGSAFES)

If you send email but don't get reply , please check the Spam.

STRUCTURE

EXTERIOR ASSEMBLY



Warning: Please do not keep the emergency key inside the safe.

FIRST OPENING



STEP 1: 1Remove the emergency lock cover by pressing down of the left side of the cover (see Figure A)

STEP 2: 2Push key in and rotate the key counterclockwise then hold it, Insert one of your backup keys into

STEP 3: 3Rotating the knob clockwise to open the safe while you hold the key

NOTICE:

- 1.When you rotate the knob clockwise, you must have the key fully inserted and turned counter clockwise to the limit, keeping the key until the safe unlocked and opened.
- 2.Please keep the keys in a secure place, do not lock the keys inside the safe.


BATTERY INSTALLATION

STEP 1: To get started, open the safe with back up key , you can refer to “ First Opening”;

STEP 2: Located the battery compartment in the back of the door;

STEP 3: Remove the battery cover;

STEP 4: Inserted 4X AA batteries into battery compartment, make sure that the batteries match the + and - in the compartment,and replace the battery cover,You are now ready to program your safe.



NOTICE:

- 1 .Please use brand-new batteries , do not mix used batteries with new batteries;
- 2 .Replace the batteries when the red indicate light turns on, it means the batteries are running out of power;
- 3.The batteries are not included,you need prepare by yourself.

.2.

PROGRAM CODE

◆ The default code is "1234#".

STEP 1: Open the safe and located the reset button in the hinge side of the door;

STEP 2: Press the button shortly and the blue light turns on;

STEP 3: Input your new code , your cod can be a minimum of 3 and a maximum of 8 digits;

STEP 4: Press # as confirming, the green light will beep twice;

STEP 5: Enter your new code as second time and press # again;

STEP 6: If the code has been recorded successfully, the green light will turn on with long beep;

STEP 7: Test your code before closing the safe.



NOTICE:

- 1.8 seconds without any operation after pressing the reset button, it will go back to standby mode, you need to retry from "STEP1";
- 2.If you make a mistake an the new code will not work, simply start over with step 1;
- 3.Programming a new cod will overwrite your previous code;
- 4.The factory fault code is 1-2-3-4-#;
- 5.When press the reset button, please make sure you press it shortly and release quickly,If you hold the button over 3 seconds, the system will go back the factory default setting.

.3.

FINGERPRINT SETTING

Your SEFR safe has the capability of storing and recognizing **29 unique fingerprint IDS**,
No fingerprint can be read in initially .

STEP 1: Open the safe and located the reset button in the hinge side of the door;


STEP 2: Press the button shortly and the blue light turns on;

STEP 3: Place your finger on the fingerprint scanner, when the safe beeps and the blue light flashes remove your finger;

STEP 4: Place finger again over the scanner until the safe beeps and blue light flashes and lift, you will repeat this process until all scans (1-5) are programmed ;

STEP 5: After 5 scans , the green light turns on to indicate success ;

STEP 6: Test the fingerprint before closing the safe.



Helpful programming Tips

Place the core of the fingerprint flat over the center of the scanner in line with side LEDS

Adjust your finger slightly between scans for increased accuracy

Notice:

1.Up to 29 fingerprint could be register;

3.8s without any operation, the system will go back to standby mode with light turns off, and you need to retry from STEP 1.

.4.

OPEN THE DOOR

Open the safe with key.

Please refer to the step "FIRST OPENING".

Open the safe with code.

Enter the new code and press #, if the code is correct, the green light will turn on . Rotating the knob clockwise to open the safe.

Open the safe with fingerprint.

Enter the recorded fingerprint, if the fingerprint is correct, the green light will turn on , Rotating the knob clockwise to open the safe.

EMERGENCY CASE

The TYPE C -USB cable is for emergency case, such as the inside batteries run out, Connect the Power bank (you need prepare the power bank by yourself) with the cable asper the picture showed. And then you can open the safe with code.



CLOSE THE SAFE

Close the door and rotate the knob counter clockwise.

.5.

ALARM SYSTEM

Continuously inputting wrong code / fingerprint with five times will activate the alarm,
The alarm will last around 60 seconds and the keypad won't accept any operation.
Open the safe with key and remove the batteries can stop the beeps.

SILENCE MODE

By hold pressing key 3 and # , you can switch tone on /tone off .

LOW BATTERY

If with low battery, the green light will flash and the keypad will beeps , please replace with brand new 4X AA batteries immediately .

CUSTOMER SUPPORT & WARRANTY

Where could I find the instruction video? To see the tutorial video:

1. Go to our Facebook: **@TIGERKINGSAFES**
2. Go to our Youtube channel:
<https://www.youtube.com/channel/UC7II4xZAK3s-cGA3Jgml9VA>
3. contact us to get the videos (24/7):

Messenger: **m.me/TIGERKINGSAFES**

Email : **Support@tigerkingsafe.com**

If you send email but don't get reply ,
please check the Spam.

go to our web
www.tigerkingsafe-us.com
click **chat with us** to have live
chat

What should I do if losing the keys?

If lost emergency key ---

The numbers on the emergency key or the number in the emergency key hole.

Customer Support /Warranty

The possible problem you might meet:

1. Cargo damaged
2. Missing accessories
3. Unsatisfied with the safe
4. Or any other setting problem

We encourage you to contact us (24/7):

Messenger: **m.me/TIGERKINGSAFES**

Email : **Support@tigerkingsafe.com**

If you send email but don't get reply , please check the Spam.

We offer 1 Year Warranty for our client and we shall find solution for you.

For details,please refer to our warranty card or contact us at

“ support@tigerkingsafe.com”.

Register your safe : www.tigerkingsafe-rg.com

Thank you for your time to read