

American Iron

Balljoint Delete System Rebuild Instructions

1. Place new bearings in freezer 30 minutes prior to assembly to cool steel for smoother insertion.
2. Remove C-clips, remove worn bearings, insert new bearings slowly/evenly, and re-install C-clips.
3. **Important**: there is very minimal clearance between the race and the C-clips to avoid any play in the assemblies in order to prolong component lifespan. After installing snap ring, tap around the ring with flathead screwdriver to ensure it is FULLY seated.

Thank you for choosing Balljoint Delete Systems by American Iron!
For offroad use only, email help@americanironoffroad.com for any questions