

WELCOME TO **b-hyve**TM


Orbit[®]

QUICK START GUIDE

Box Contents

A Wi-Fi Hub

B Quick Start Guide




1) Power Your Wi-Fi Hub

Plug the Wi-Fi Hub into an indoor outlet.

Choose an indoor location for your hub near the outside location of your timer and within range of Wi-Fi.



Avoid areas where the signal must travel through more than one wall, dirt, or thick steel barriers.



2) Enter Pairing Mode

Press the B-hyve button to enter into pairing mode. Your hub will flash a blue light every 5 seconds.




To activate pairing mode press the B-hyve button 5 times. The light will flash red, then blue, to indicate that the timer has been reset and is back in pairing mode.

3) Open the B-hyve App

Once you are in the B-hyve App, tap on settings, tap devices, and finally tap add device. The app will walk you through the rest of the process.




For new users, search for "B-hyve" and download the free Android or iOS app. Create an account to begin timer setup.



4) Complete Setup

Once you complete setup you can start adding timers to your hub.

Scan for access to a full user manual, videos, and more. Or visit us at: bhyve.orbitonline.com



Hub

Range: 150 ft without interference
Temperature Operating Range: 32°F-104°F (0-40°C)
Storage Temperature: -4°F to 140°F (-20 °C to 60 °C)
Humidity Operating Range: 0-90%
Input: 100-240V ~ 50/60Hz 0.2A
Output: 5V-1.0A
For Indoor Use Only

FCC Statement: FCC ID: ML6-BH1

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device meets the FCC and IC requirements for RF exposure in public or controlled environments. The end user is advised to maintain a distance 20 cm from the timer and any personnel to ensure compliance with RF exposure regulations.

IC Statement: IC: 3330A-BH1

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This Class B digital apparatus complies with Canadian ICES-003.

Remarque: cet appareil a été testé et déclaré conforme aux limites d'exposition pour les appareils numériques de classe B, selon la section 15 de la Réglementation de la FCC. Ces limites sont conçus pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet appareil produit, utilise et peut émettre de l'énergie radio fréquence et, si elle n'est pas installée et utilisée conformément aux instructions, peut causer des interférences nuisibles aux communications radio. Cependant, il n'est pas garanti que des interférences ne se produisent pas dans une installation particulière. Si cet appareil cause des interférences gênantes à la réception d'un signal radio ou de télévision, ce qui peut être déterminé en allumant et en éteignant l'appareil, l'utilisateur peut corriger les interférences en suivants une des mesures suivantes :

- Réorientez ou repositionnez l'antenne de réception.
- Augmentez la distance entre l'appareil et le récepteur.
- Branchez l'appareil dans une prise sur un circuit différent du circuit sur lequel le récepteur est branché.
- Consulter le revendeur ou un technicien radio/TV expérimenté pour obtenir de l'aide.

Cet appareil est conforme aux exigences de la FCC et de l'IC concernant l'exposition aux ondes dans un environnement public ou contrôlé. Il est conseillé à l'utilisateur final de maintenir une distance de 20 cm du contrôleur pour assurer la conformité aux réglementations d'exposition RF.

Information de conformité pour le Canada Déclaration de l'IC : Cet appareil est conforme à la norme RSS d'Industry Canada. Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit tolérer toutes les interférences, dont les interférences pouvant causer un fonctionnement non désiré. Cet appareil numérique de classe B est conforme à la norme canadienne ICES-003.

Consulte el manual del usuario en línea para obtener instrucciones en español.

Need Help?

If the app and the website don't have what you're looking for, please call our technical support line before returning the B-hive to the store. Have your MAC ID ready.

1-800-488-6156 | support@orbitbhyve.com

Timer MAC ID: ____:____:____:____:____:____

Hub MAC ID: ____:____:____:____:____:____

PN 21006-50 rB

