

Turbo Column




the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.


Use minimum 90°c supply conductors.

Install the Column



Wire the Column






Connect the neutral power line wire to terminal block connected to the white wires.

Connect the hot power line wire to terminal block connected to the black wires.

- Use the gray and purple dimming wires for 0-10v dimming application (if not in use, make sure to cap these wires off).
- 9 Reinstall the access panel (reversal of section 2A).


Warning: The purple and gray wires are only used for 0-10v dimming. For all other applications, do not connect the gray and purple wires.




9 Use the gray and purple dimming wires for 0-10v dimming application (if not in use, make sure to cap these wires off).

10 Reinstall the access panel (reversal of section 2A).

Note for Photocell equipped fixtures: at initial power up, the photocell must calibrate which will cause the fixture to cycle on/off for a moment.





Use the gray and purple dimming wires for 0-10v dimming application (if not in use, make sure to cap these wires off).

B Reinstall the access panel (reversal of section 2A).

Note for In-Line Fuse equipped fixtures: in the case that the fixture is not operating correctly, make sure to check the fuse.

Note for Photocell equipped fixtures: at initial power up, the photocell must calibrate which will cause the fixture to cycle on/off for a moment.

