

INSTALLATION GUIDE

RYKER FLOORBOARD AJUSTMENT

DIFFICULTY LEVEL AND INSTALLATION TIME

DIFFICULTY LEVEL:
EASY

ESTIMATED TIME:
10 MIN

RECOMMENDED TOOLS

- ***ALLEN KEY 8MM***
- ***RATCHET (OPTIONNAL)***



1

HERE'S AN EXAMPLE OF A POSSIBLE ADJUSTMENT WHICH OFFERS NATURAL ERGONOMICS.



2

BY RELEASING THE LATCH, THE FLOORBOARD WILL COME IN CONTACT WITH THE BODYWORK.



3

THE BEST WAY IS TO UNBOLT THE FLOORBOARD WITH A 8 MM ALLEN KEY, THEN INVERT IT (PUT IT UPSIDE DOWN)



4

NOW DISENGAGE THE LATCH AND CHOOSE THE PREFERRED POSITION.



5

LOCK THE LATCH, FLIP THE FLOORBOARD ON THE CORRECT SIDE AND NOW CHOOSE THE PREFERRED ANGLE.



6

IN CONCLUSION, IT IS VERY IMPORTANT TO TIGHTEN THE ANGLE ADJUSTMENT BOLT AT 35 FOOT POUNDS.

7



HERE'S AN EXAMPLE OF A POSSIBLE ADJUSTMENT WHICH OFFERS NATURAL ERGONOMICS.

8



IF YOU TRY TO DISENGAGE THE LATCH WHICH ALLOWS THE FLOORBOARD TO SLIDE FORWARDS AND BACKWARDS, IT WILL COME IN CONTACT WITH THE BRAKE PEDAL.

9



THE BEST WAY IS TO UNBOLT THE FLOORBOARD WITH A 8 MM ALLEN KEY, THEN INVERT IT (PUT IT UPSIDE DOWN)

10



NOW DISENGAGE THE LATCH AND CHOOSE THE PREFERRED POSITION.

11



LOCK THE LATCH, FLIP THE FLOORBOARD ON THE CORRECT SIDE AND NOW CHOOSE THE PREFERRED ANGLE.

12



IN CONCLUSION, IT IS VERY IMPORTANT TO TIGHTEN THE ANGLE ADJUSTMENT BOLT AT 35 FOOT POUNDS.