

# Assembly Instructions

## Summit Rivet Workbench

SRVB994 / SRVB9126

**Tools required:**

- Hammer or Rubber Mallet.

**Recommendations:**







- Use a cloth or wooden block to protect components when hammering.
- Hammer gently to avoid component damage.
- Assembly is recommend with two people.


**Caution:**

- Wear gloves during assembly.
- Handle components with care due to possible sharp corners.
- Assemble the unit on a solid, level surface.


**Parts List**

Please read through all the instructions and verify that all parts are present before beginning assembly.

- |  |                                      |     |
|--|--------------------------------------|-----|
|    | <b>A Uprights</b>                    | x 4 |
|    | <b>B Long beam</b>                   | x 4 |
|   | <b>C Short beam</b>                  | x 4 |
|  | <b>D Shelf brace (SRVB9126 only)</b> | x 2 |
|  | <b>E Plastic end cap</b>             | x 4 |
|  | <b>F MDF Shelf</b>                   | x 2 |



**Step 1** - Start by joining a long beam and a short beam to an upright. Be sure to have the flat edge of the beams facing up. Repeat for each upright and attach the plastic end caps as shown.



**Step 2** - Complete the workbench by adding the shelf braces (SRVB9126 only) and MDF shelves.