



# WINDOW PANEL TRACTION BOARD MOUNTS

I N S T A L L   I N S T R U C T I O N S


# HARDWARE CHECKLIST

Exact hardware color counts may vary based on the options selected at checkout.

---

**2**

Sherpa Traction Board Mounts



**8**

1/4"-20 Hex bolt (1")



**8**

1/4"-20 Nylock nut



**16**

1/4" Washer






## BEFORE YOU BEGIN

It is highly encouraged that all accessories on the window panel are installed while the panel is off of the vehicle. This makes it much easier to position the part and tighten down fasteners.

## Setup

Install the locking pins from your traction board manufacturer on the Sherpa Traction Board Mounts using the hardware that was supplied with the kit. **Adjust** the pins in the slots so that the pins will fit in the holes in the traction board.






Passenger side

## Install 01

Line the traction board mounts up with the [designated holes](#) in the window panel. Pictured is a 5th Gen 4Runner window panel, but all panels will have similar holes or slots that the traction board mounts utilize. These locations have been specifically placed in order to allow clearance between the door of the vehicle and the tip of the traction board.



Driver side

## Install 02

Required Components:

**8** 1/4"- 20 x 1" Hex bolt


**8** 1/4"- 20 Nylock nut


**16** 1/4" Flat washer

Place your traction board over the pins to ensure fitment. If the pins do not fall into the holes in the traction board, make the appropriate adjustments in the traction board mounts. If adjustments are needed, it is preferable to slide the board backwards toward the rear of the vehicle as opposed to forward. This is to ensure that the rear door is unobstructed.


Once the traction board mounts are in the right locations, secure them down using the supplied hex bolts, nylock nuts, and flat washers as shown in the image below.

Note that the bolts are inserted from the back side of the panel so that the excess threads and nuts are facing away from the glass of the window once mounted.






Passenger front view




Passenger rear view



## Install 03

Attach the traction boards as a final verification that the mounts are in the correct location. Hold the assembly up to the vehicle where it will be mounted and visually confirm that the vehicle door will have the clearance to open.

Once the traction board mounts are installed, ensure all fasteners are tight. The window panel is now ready to be installed on the vehicle.



# EXPLORE.

All products built and designed by Sherpa Equipment Company are intended for off-road use and should be assembled, installed, and used according to Sherpa Equipment Company's recommendations. Sherpa Equipment Companies products should be used safely with good judgment towards others and surroundings.

By installing Sherpa Equipment Companies products on your vehicle you assume all liability. Sherpa Equipment Company will not be held liable for damages or loss associated with the installation or use of its products. It is recommended that you inspect your roof rack within the first 100 miles of installation and every 500 miles after.