



## PAROPY CL WATER SLIDE

### APPLICATION INSTRUCTIONS

#### NOTES

##### Recommended Materials

White or Light Colored Candles  
Glass  
Metal  
Wood  
Soap

##### Accessories Required

Computer, Color Laser Printer, Large Water bowl, Dish Soap, Plain Paper, Plastic bag or plastic wrap.

##### Printable side

The printable side is the white glossy coated side.

##### Storage

Paropy CL Water Slide has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight, and humidity.

##### Tips

For extra durability on candles, we suggest using a glue stick to help adhere the WT transfer paper.

The candle can also be heated with a blow dryer to soften the wax before applying the transfer.

#### STEP BY STEP

Paropy CL Water Slide will allow image transfer to objects that cannot be heated with a heat press.

This paper will work in most Oil and Non-Oil Laser Copiers and Printers. It is recommended that you do a test before commercial application.

##### Step 1

Feed transfer paper into laser printer so that the printer is printing on the printable side (white glossy coated side). It is recommended to use the bypass tray when printing.

##### Step 2

Design your image and and resize if necessary. Do not mirror image the design

##### Step 3

Trim the imaged Water Slide paper as close as possible without cutting into image using scissors/exacto knife.

##### Step 4

Fill suitable sized bowl with water and add about 5-10% liquid dish soap.

##### Step 5

Put a piece of plastic wrap on the counter or work surface. Put a little water from the bowl on the plastic wrap. Then place the imaged paper in bowl for 5-10 seconds.

##### Step 6

Put wet WT paper from the bowl on pre wet plastic bag/wrap face down. Absorb access water with a plain piece of paper.

##### Step 7

Gently remove paper backing from plastic bag/wrap. Place the imaged plastic bag/wrap on top of material to be printed. With sponge and finger, gently correct position of image and iron out air bubbles.

##### Step 8

Let the transfer and material dry for at least 1 hour before handling.