Chemical Consultants INCORPORATED

IW-108

Multi-Purpose Screen Wash

GENERAL DESCRIPTION

IW-108 is a water soluble ink degradent. It is highly effective on plastisol, multipurpose (solvent based), poster, UV, and vinyl inks. IW-108 will protect the fabric from deep stains or ghosting from the image print. This makes it much easier when complete reclamation of the screen is necessary.

IW-108 can be used in a wide variety of innovative cleaning processes ranging from re-circulation machines, dip tanks, immersion cleaning processes, and automatic reclaiming machines. It can also be applied manually with a scrub pad, spray bottle, or pneumatic pump systems.

IW-108 is also an excellent plastisol ink haze (ghost) remover. It is nonhazardous (non-corrosive) and aggressively removes image stains from the mesh.

ADVANTAGES

- Low Odor
- High Solvency
- High load capacity to reduce usage
- High flash point / Non-flammable
- Non-Hazardous
- Mesh safe
- Multiple applications

APPLICATIONS

Always card excessive ink from screen. Use one of the following applications.



INK WASH-OUT AT THE SINK:

Card excessive ink from the screen. Apply IW-108 to ink side of screen. Use a non-abrasive scrub brush or pad to agitate ink on both sides of screen. Finally, rinse away all residue away using high pressure water.

Haze Remover:

RECIRCULATING WASH: Card excessive ink from the screen. This product can be continuously recirculated until product becomes too heavily soiled with solids. Used product may be filtered and reused.

After ink and emulsion has been removed, spray IW-108 on both sides of the screen. Scrub screen both sides with a non-abrasive brush or pad. Allow product to dwell a few minutes (depending on severity of stain). High pressure rinse screen working from bottom and moving upwards.

> 4 x 4 Stainless Steel **Recirculating Booth** Click here for more details.



Packaging

1 gallon 5 gallon pail 55 gallon drum

1850 Wild Turkey Circle Corona, CA 92880 PHONE(951)735-5511 FAX(951)735-7999 www.ccidom.com

Quick Tip:

Always pressure wash screen from the bottom and work upwards.

This will prevent ink from locking back onto the mesh when coming in contact with the rinse water.