




INCLUDED

- 1x ScentBard Diffuser
- 1x ScentBard Manual
- 1x SafeLock Key
- 1x Wall Mount Bracket
- 1x Wall Mounting Hardware (3 wall anchors + 3 screws)
- **Sold Separately:** Bottle w/fragrance, USB-C Power Cord, D Batteries (4)



ScentBard Diffuser



Screws



SafeLock key



Wall Mount Bracket



Atomizing Head



GETTING STARTED

1. Insert the SafeLock key in the side of the diffuser and twist it to the Open position
2. Lightly press on the indent near the lock and open the door of the diffuser
3. Remove the atomizing head by pulling it toward you
4. Insert the straw into a bottle of ScentBridge fragrance oil and tighten atomizing head fully
5. Reinstall the atomizing head with attached fragrance bottle back into the diffuser
6. Choose **Power** or **Battery** mode by sliding the labelled switch; plug in or insert batteries
7. Wait ~12 minutes to charge if the diffuser has not been powered on in over 7 days
8. Close door, reinsert SafeLock if desired (diffuser will operate normally even if lock is not inserted)
9. Adjust grade settings and schedule as needed in ScentSetter App



TROUBLESHOOTING

Before reaching out to our technical personnel, please take a look at the following possible solutions. If you need further assistance, please email us at service@scentbridge.com

Diffuser Not Connecting to Smart Device:

- Quit the ScentSetter app
- Turn off Bluetooth on your smart device, then unplug or remove batteries from ScentBard diffuser
- Turn the smart device's Bluetooth back on, then plug ScentBard diffuser back in or reinsert battery
- Listen for the diffuser to beep, then open the ScentSetter app and select the diffuser

Weak or No Diffusion:

- Check to ensure the machine is not in a "non-working period"
- The air pump may be damaged, replace if still under warranty
- Check to ensure the tube is not loose

Oil Leaking or Spraying:

- Check to ensure the atomizing head is pushed in fully
- The bottle is not fully screwed into the atomizing head
- The atomizing head is damaged, contact support if still under warranty



USER MANUAL

ScentBard

WIDE AREA FRAGRANCE DIFFUSER

TABLETOP OR WALL MOUNT USE
BLUETOOTH APP CONTROL
ANTI-TAMPER 'SAFELOCK'



ScentBridge

- ☎ 833 723 6835 - OPTION 1
- ✉ SERVICE@SCENTBRIDGE.COM
- 🌐 SHOP.SCENBRIDGE.COM
- 📍 20 INDUSTRIAL DRIVE E,
SOUTH DEERFIELD MA 01373



APP GUIDE

Search the Google Play Store (Android) or the App Store (iOS) for "ScentSetter"

TO LOG IN

- Ensure Bluetooth is enabled on your smart device
- Open the app and tap diffuser name (default is a string of letters and numbers that can be renamed later)
- Enter the default password "8888" and tap "Login"
- The system will beep when connected

Tap either **Name** or **Label** to edit, then tap 'save'

TO ADD WORKING PERIODS (add up to 5)

Press (+) to add a new Working Period

The schedule example above will diffuse fragrance Monday through Friday from 6AM - 1PM at Grade 4, Then Saturday and Sunday 2PM - 11PM at Grade 2



APP GUIDE CONTINUED

TO EDIT WORKING PERIODS

Start working time: When diffusion will begin

Stop working time: When diffusion will cease

Grade: Strength of diffusion. All Grades repeat a diffusion period of 10 seconds, followed by a pause interval. The larger the grade, the more frequent the diffusion

TO CHANGE PASSWORD

Tap "About"

Tap "Change Password"

Enter new password and tap "Confirm"



WALL MOUNTING - RECOMMENDED

1. Line up the mounting bracket where you would like to install the diffuser on the wall and mark where the screws will go
2. Drill holes in the wall. Insert the wall anchors, then place the bracket on the wall, align the 3 holes with the wall anchors and screw 3 screws into anchors
3. Hang the diffuser on the bracket



CAUTION / WARNING

1. Keep the machine upright. Tilting or laying flat will cause the oil to over flow and damage surfaces
2. ScentBridge fragrance oil is specially formulated to work optimally with all ScentBridge diffusers. Other oils may cause damage or poor performance
3. Do not use quick charger to power diffuser
4. Do not disassemble or attempt to repair the diffuser. If any failure happens to the machine, please see the Troubleshooting section



SPECIFICATIONS

Bottle Capacity:	480ml
Power:	1.1W
Coverage:	up to 1600 sq.ft.
Material:	Plastic
Weight:	600g
Color:	White / Black



CLEANING

The machine should be cleaned when:

- You're are switching to a different oil
- The atomization volume becomes weak

Cleaning steps:

- Remove the atomizing head & bottle from the diffuser
- Separate the head from the bottle and place the bottle safely where it won't spill
- Use a larger container filled with industrial alcohol to soak the atomized head for 5-10 minutes
- Allow the atomized head to air-dry then reinstall