

TeamTM


Replacement Boat Hook

INSTRUCTIONS

This boat hook end is a direct replacement for all Davis and Davis TeamTM boat hooks. Also fits EEz-In boat hooks and others using tubing 1" and 1 1/4" diameter (2.5 and 3.2 cm) and .035" wall thickness (.89 mm).

The World's Strongest Boat Hook End

3/4" (19 mm) Acme Thread
accepts brushes, mops, etc.



Extra Thick Neck and Body add to durability.



Bright Orange Vinyl Tip protects boat's finish, aids visibility and eye-hand coordination.

Hole Molded in Tip for securing hook or attaching small line for use with tarps or awnings.

Curved Head for fending off stanchions and lines.

Ribbed Hook and Unbreakable Lexan[®] — tougher by design, lighter than (brittle) metal alloy ends.

All Team[®] boat hooks float!



Replacement Kit includes:



Boat Hook Tip

Plastic Adapter Sleeve

Stainless Steel Drive Rivets

Davis Instruments

3465 Diablo Ave., Hayward, CA 94545 U.S.A.

Phone (510) 732-9229 • Fax (510) 732-9188

info@davisinstrumentc.com www.davisinstruments.com

INSTALLATION INSTRUCTIONS

Use method appropriate for your type of original pole.


METHOD A



Davis with white hook

All Davis and Team boat hooks and paddle boat hooks with white plastic hook

1. Using a pliers or "vise-grip" tool, remove both drive screws securing the old boat hook tip. Tightly grip the sides of the drive screws before turning them counter-clockwise. If, for some reason, you cannot get a good grip to back them out, try Method B.



2. Pull out stub of broken boat hook tip.
3. **If telescoping pole:**
Insert new boat hook tip into the adapter sleeve and then insert both into tube.
If fixed length pole:
Insert new boat hook tip directly into tube.
4. Using a #24 or 5/32" (4 mm) drill bit, drill a hole through each old screw hole into the new boat hook fitting.
5. Locate the drive screws furnished in the repair kit. They are a special type of screw that is installed with a hammer. One or two solid taps is all that is needed to seat them. Insert new drive screws into old screw holes and hammer them home. Do not use excessive force.

METHOD B



Davis with black hook

All Davis and Team products with with black plastic hook


With Davis Versapoles™ this method is a permanent replacement. For a removable replacement boat hook, contact Davis Customer Service at 800-678-3669.



EEz-In®

All EEz-In® boat hooks

with grey metallic-looking hooks on 1" (25.4 mm) diameter poles




Other 1 or 1 1/4" poles

All other poles


having a tube outside diameter of 1" or 1 1/4" (25.4 or 32.0 mm) and a wall thickness of .035" (.89 mm)

1. Use a tube cutter or hacksaw to cut off the old or broken boat hook tip 1 1/2" (38 mm) from end of tube. Be careful to make the cut as square as possible. **CAUTION: Extend telescoping section before cutting.**



2. Deburr cut as necessary to insert replacement boat hook tip.
3. **If EEz-In or any brand with outside tube diameter 1" (25.4 mm):** Insert new boat hook tip directly into cut end of tube.

4. Using a #24 or 5/32" (4 mm) drill bit, drill through aluminum tube and boat hook tip about 3/8" (10 mm) from end of tube.



5. Locate the drive screws furnished in the repair kit. This is a special type of screw that is installed with a hammer. One or two solid taps is all that is needed to seat them. Insert new drive screws into screw holes and hammer them home. Do not use excessive force.