

## To open the filter chamber



**Turn over**  
the Airpura




**Remove** the 4  
retaining screws



**Take off**  
the cover




**Remove**  
the gasket



**Position**  
the Prefilter  
inside the filter  
chamber




**Place** a felt gasket at  
the bottom of the  
filter chamber




**Place** the HI-C filter  
around the HEpa filter and  
Attach the HI-C filter with  
the elastic bands




**Unfold the filter slider**  
(Supplied with replacement  
filters or on request  
Part#6F 001)




**Roll it**  
into a spiral




**Insert** the tube into  
the filter chamber  
inside the Prefilter



**Let** the spiral open to  
fill the opening




**Open** the top of the  
spiral to make a  
slight funnel




**Insert** the  
Carbon canister  
into the funnel and  
hold it straight



**Let** the canister  
slide down  
the filter slider



**Pull** the filter slider  
up out of the cavity  
using both hands  
and let the canister  
slide to the bottom  
of the cavity



**Remove** the filter  
slider and fold it for  
further use



**Slide** in the  
HEpa filter

**Airpura**   
AIR PURIFIERS

# G700

OPERATING  
&  
FILTER REPLACEMENT  
DIRECTIONS

## To close the filter chamber



**Replace**  
the gasket



**Position** the  
indentation in the cover  
into the center of the  
HEPA filter



**Replace**  
the 4 screws  
and tighten



**Turn** the Airpura  
back on casters

# TO BEGIN USING YOUR AIRPURA

**Inspect the exterior of your Airpura** to verify there is no damage from shipping. If any damage is noted, please follow the instructions from the distributor returns policy.

**Wipe the unit** with a damp cloth to remove any dust from packaging

**Plug the unit** into a regular grounded 110 volt outlet

**Turn on the unit** to MAX and allow it to run for at least 30 minutes

**Set the variable speed** control to the level you wish

The most efficient way to use your Airpura for regular air quality maintenance is to run it at a low speed **24 hours a day 7 days a week.**

**Always maintain a humidity level of 40% in your home to ensure the unit is operating at optimal levels. When using purifier with a dehumidifier, keep dehumidifier at least 6 feet away.**



## FILTER MAINTENANCE AND REPLACEMENT

### The Prefilter


Can be vacuumed from the exterior of the unit once a month or more often. Should be replaced at least after 12 months of use

### To vacuum the Prefilter


Use the brush attachment on your vacuum cleaner  
Vacuum slowly around the mesh surface of the filter chamber

## IMPORTANT SAFETY NOTE


Please ensure air purifier is turned OFF when plugging into a power source. Failure to do so may result in motor potentially stalling and/or burning.



**Poly Prefilter 600 2-pack**  
12 months



**HEPA 600RVHU Filter**  
(99.97% efficient @ 0.3 Microns)  
3 to 5 years



**18 lbs German Carbon Filter**  
12-24 months

## Technical specifications

### Odor, airborne chemical control

18 lbs German carbon Filter  
carbon 13"H x 13.25"OD x 9"ID

### Carbon bed

570 in<sup>2</sup> x 2 in deep

### Particle removal

40 sq ft true HEPA  
(Measured 1 side only)  
12 pleats per inch  
Pleats warm rolled with separators

### Air flow 635 cfm

More cfm than any other home unit available

### Pre-filter

570 in<sup>2</sup> x 1 in deep

### Size

23 in x 15 in

### Weight

45 lbs total

### Voltage options

110 or 220 volts

### Watts

120 on high / 40 on low

### Sound level

**30.2\*** db on low (at 6 feet)  
63.0 db on high (635 cfm)  
\*at test conditions



## Air purifiers models and filter configurations

	Prefilter	Particulate	Carbon
Alternates	Cotton Prefilter TarBarrier Prefilter		