

# Assembly Instructions for 44" Square Walk-In Table

## Tools Needed:

Power drill or screwdriver  
#2 Square Drive Bit

## Hardware:



4 – 2¾" Wafer Head Bolts  
75– 2" Screws  
1 - Allen Wrench

## Parts List:

Table Top—2 pieces  
2"x2"x35" Strips—2 pieces  
Table Leg Assemblies—2 pieces  
Bench Tops - 4 pieces  
1"x5½"x14½" Bench Leg Supports—8 pieces  
1"x5½"x32" Bench Bottoms—4pieces


## Step 1

Lay the table tops upside down & bolt together. Insert the four 2¾" bolts in the predrilled holes in one side & turn into the threaded inserts with the Allen Wrench. (See photo 1.) Now, attach the 2"x2"x35" strips, use six 2" screws in each strip. Turn into the predrilled holes and screw down into the table top. (See photo 2.)



## Step 2

Assemble the 4 bench legs. Take two leg supports and attach to a bench bottom. Put two 2" screws in the predrilled holes in each end of the bench bottom and screw into one end of the leg supports. (See photo 3.)





\*Keep 2x2 even with leg supports\*

## Step 3

Unfold a table leg assembly & place upside down on a table. (See photo 4.) Take a bench top & place upside down with the center 2x2 between the 2x4 table leg support beams. Attach with two 2" screws on each side (See photos 4 and 5)

### Step 4


Now take the bench leg assemblies in Step 2 and place them on the seat. Center with the 2x2 on the bench top. Attach with two 2" screws on each end. (See photos 6 & 7.)



*\*Center on 2x2 strips\**

### Step 5

Fold the center leg down and attach to the bench bottom. Put one 2" screw in the predrilled hole in the center of the bench bottom and screw up into the leg. (See photo 8.) Now, put the 2 base assemblies together (See photo 9.)



### Step 6

Place the table top on the base and latch down into the 4 corners between the 2x2 braces. (See photo 10.) Put one 2" screw into each 2x2 and screw into the top of the legs. (See photo 11.)

