



Required Tools:


- Mallet/Non-Marring Hammer
(DO NOT Use Metal Headed Hammer)
- 1/2" Wrench or Socket
- #2 Square Drive bit

Hardware:

- (6) 2 1/2" Screws
- (2) 3" Screws
- (10) 5/16" x 3 1/2" Bolts
- (2) 5/16" x 3" Lag Bolts
- (6) 5/16" Washers
- (10) 5/16" Flange Nuts
- Swing Chains

Parts:

- A = (1) Seat
- B = (1) Backrest
- C = (1) Left Arm Assembly
- D = (1) Right Arm Assembly
- E = (1) 2x4 Brace
- F = (1) Chain



Step 1

Attach the seat (A) to the backrest (B) using (2) 5/16" x 3 1/2" bolts and (2) 5/16" flange nuts. Repeat step on opposite side.



Step 2

Attach the right arm assembly (C) to side of the seat using (2) 5/16" x 3 1/2" bolts and (2) 5/16" flange nuts. Repeat with left arm assembly (D) on the other side.



Step 3

On the underside of the swing. Attach the 2x4 brace (E) to underside of the seat and into the angle iron, using (6) 2 1/2" screws.



Step 4

To attach the armrest and chain (F) to the backrest, put (1) 5/16" x 3 1/2" bolt through the last link in the shorter section of chain, and add a (1) 5/16" washer before inserting it through the arm and through the backrest, once through add the 5/16" flange nut and tighten. Repeat with other arm rest.



Step 5

Slide a 5/16" washer onto a 5/16" x 3" lag bolt and insert it through the last link of the other end of the chain, add an additional 5/16" washer and fasten the hardware to the end of the 2x4 as shown. Repeat on the other side.



Step 6

On the back side of the swing, fasten the backrest to middle seat support with (2) 3" screws. Your swing is now complete... enjoy!
Thank you for purchasing from Wildridge.