



Required Tools:


- Mallet/Non Marring Hammer
(Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive bit
- 1/2" and 9/16" Wrench or Socket

Hardware:

- (4) 5/16" x 5" Bolts
- (8) 5/16 x 3" Lag Bolts
- (6) 5/16" x 3 1/2" Bolts
- (8) 5/16" Washers
- (10) 5/16" Flange Nuts
- (8) 3/8" x 2 1/2" Machine Bolts
- (8) 3/8" Locknuts
- (16) 3/8" Washers
- (2) 3" Screws
- (4) Glider Brackets

Parts:

- A = (1) Backrest
- B = (1) Seat
- C = (1) Right Arm/Leg Assembly
- D = (1) Left Arm/Leg Assembly
- E = (2) Base Pieces
- F = (2) Cross Members




Step 1

On a level surface, place the backrest (A) and the seat (B) on its side, butting them up against each other. Lay the right arm/leg assembly (C) onto the backrest and seat and fasten them together. For the front leg use (2) 5/16" x 3 1/2" bolts and (2) 5/16" flange nuts. For the back leg use (2) 5/16" x 5" bolts & (2) 5/16" flange nuts, and for the armrest use (1) 5/16" x 3 1/2" bolt & (1) 5/16" flange nut. Repeat with the left arm/leg assembly (D) on the other side.



Step 2

Place the glider upright. On the backside, fasten the backrest to the seat support using (2) 3" screws, as shown, through the pre-drilled holes provided.





Step 3

Pictured top left is a base piece (E) for reference.

Please note the hole placement difference in the ends of the two base pieces. One end goes towards the front of the glider and the other end will go towards the back of the glider. Both base pieces will have the same hole configuration - but on opposite sides. The bolts will go through the four holes that are to the left and right of the pre-attached board. Do not put the bolts in the holes on the top of the base pieces, those are for the glider bracket hardware in step 4.

Turning the base pieces (E) so the pre-attached board faces outward, attach them to the two cross members (F) with (8) 5/16" x 3" lag bolts and (8) 5/16" washers (the washer should go onto the bolt before attaching), through the holes provided.

Note: The front of the base will be the front of the glider when you are assembling the base and glider assembly in step 4.



Step 4

Using the picture above as a reference, fasten the hardware through the top holes on the two base pieces, using (1) 3/8" x 2 1/2" machine bolt, (2) 3/8" washers, (1) glider bracket and (1) 3/8" locknut, per hole. Note: the glider bracket should be on the outside of the base so you can attach it to the leg in step 5. For it to glide correctly the hardware must be placed in the order that is pictured above and with the curve on the glider bracket facing away from the base. You will be doing this for all four glider brackets.



Step 5

Place the glider assembly onto the base assembly and attach each leg to a glider bracket using (1) 3/8" x 2 1/2" bolts, (1) 3/8" flange nuts, and (1) 3/8" washer. Your glider is now complete.

Thank you for purchasing from Wildridge.