**Required Tools:**


- 7/16" Wrench or Socket
- Mallet/Non-Marring Hammer (DO NOT Use Metal Headed Hammer)
- #2 Square Drive Bit
- Cordless Drill

Hardware:

- (8) 1/4" x 2 1/4" Bolts
- (10) 1/4" Flange Nuts
- (4) 2" Screws
- (2) 1/4" x 2 3/4" Bolts
- (8) 1 1/4" screws

Parts:

- A: Back
- B: Seat
- C: Legs
- D: Brace
- E: Left Armrest
- F: Right Armrest

**Step 1**

Place the seat on a level surface. Fasten the back (A) onto the seat (B) using (4) 1/4" x 2 1/4" bolts (2 on each side) and (4) 1/4" flange nuts (2 on each side) thru the pre-drilled holes.

**Step 2**

Place one of the legs (C) with the bracket support up and facing outward, as shown onto the side of the front of the seat. Fasten together with (2) 1/4" x 2 1/4" bolts and (2) 1/4" flange nuts. Repeat on other side.



Step 3
Using (2) 2" screws, attach the brace (D) to the legs. Repeat on the other side.



Step 4
Attach the left armrest (E) to the back of the left side of the chair (as pictured) with (1) 1/4" x 2 3/4" bolts and (1) 1/4" flange nut. Repeat on the right side with the right arm rest (F).



Step 5
On the front of the armrest measure a 3/4" overhang on the inside as shown, fasten the armrest using (4) 1 1/4" screws. Repeat on the other armrest.



Step 6
Your chair is complete.... enjoy!

Thank you for purchasing from Wildridge.