

#### Required Tools:

- Mallet/Non Marring Hammer  
(Do not use Metal Headed Hammer)
- 7/16" Wrench or Socket
- Cordless Drill
- 6" #2 Square Drive bit
- Tape Measure

#### Hardware:

- (16) 1 3/4" Screws
- (4) 1 1/4" Screws


#### Parts:

##### (For Dining Chair)

- A = (1) Seat
- B = (1) Backrest
- C = (2) Front Legs
- D = (3) Leg Supports


#### Step 1

On a soft surface, lay seat (A) upside down. Place a leg (C) with the holes facing inward up against the apron on the seat as shown, and fasten with (2) 1 3/4" screws through the pocket holes and into the seat brace. Fasten the other leg (C) on other side, in the same manner.



#### Step 2

Lay seat (A) and backrest (B) on its side. Measuring 14 1/2" from the bottom of the leg to the bottom of the seat and fasten them together with (2) 1 3/4" screws thru the pocket holes provided. Repeat on other side.



#### Step 3

Lay chair on its back. Fasten a leg support (D) between the front and back leg, keeping it flush on the inside and 2 3/4" up from the bottom (use one of the other leg supports as a guide for height). Fasten with (4) 1 3/4" screws. Repeat on other side.



Use the extra leg support as your measurement for the placement of the leg support you are installing.



#### Step 4

Now fasten the remaining leg support in the center between the two other leg supports, as shown, measuring so its half way between on both sides and fasten with (4) 1 1/4" screws, 2 on each side. Note: DO NOT use 2" screws on this support.



#### Step 5

Your chair is now complete.

*Thank you for purchasing from Wildridge.*