

**Required Tools:**

- Cordless Drill
- #2 Square Drivebit
- 7/16" Wrench or Socket

**Hardware:**

- (8) 2" Screws
- (8) 2 1/2" Screws
- (8) 1/4"x2" Bolts
- (8) 1/4" Flange Nuts
- (16) 1 1/4" Screws



**Parts:**

- A = (1) Table Top
- B = (4) Legs
- C = (8) Braces
- D = (1) Shelf
- E = (2) Stilts



**Step 1**


Turn table top (A) upside down on soft surface. Locate the four legs (B) and tap (2) 1/4"x2" bolts through the holes on each of the legs.



Slide Bolts Through Holes

**Step 2**

Place one of the legs (B) into place, as shown, then slide the bolts through the holes in the frame, and add (2) 1/4" flange nuts and tighten. Repeat with remaining three legs.



**Step 3**


Place one of the braces (C) up against a leg and the aluminum frame, as shown. Using (2) 1 1/4" screws, attach the brace to the aluminum frame thru both holes from the inside.




**Step 4**  
Then attach the same brace to the leg with (1) 2" screw, as shown.



**Step 5**  
On the other side of the leg, attach another brace in the same manner as Step 3 & Step 4. Repeat with three remaining legs and six remaining braces.



**Step 5**  
Stand the table upright, and place the (2) stilts (E) in place as pictured left. Set the shelf (D) onto the two stilts to hold it up during installation, making sure the shelf is turned the same way as the table top above, so the boards run parallel with each other, then fasten the shelf to the legs through the holes provided with (8) 2 1/2" screws, 2 per leg. Discard stilts.



Your table is now complete.

*Thank you for purchasing from Wildridge.*