

Required Tools:


- Mallet/Non Marring Hammer
(Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive bit
- 7/16" Wrench or Socket
- Tape Measure

Hardware:

- (8) 1/4" x 2" Bolts
- (8) 1/4" Flange Nuts
- (8) 2 1/2" Screws
- (8) 2" Screws
- (8) 1 1/4" Screws


Parts:

- A = Table Top
- B = Leg Assembly
- C = Leg Braces
- D = Table Support Braces
- E = Umbrella Support Brace




Step 1

Lay the table top upside down on a soft surface and line up the holes on the leg assemblies (B) with the holes on the metal table frame. Attach with (8) 2" bolts and flange nuts, 2 per leg.




Step 2

Place one leg brace against each leg, as shown (**NOTE:** Two of the leg braces have been shortened to clear the center angle iron). Fasten one of the leg braces to the angle iron with (2) 1 1/4" screws, then screw the brace to the leg with (1) 2" screw. Repeat with remaining legs.



Step 3

Set the table upright and fasten the table support braces (D) on the inside of legs with (2) 2 1/2" screws per leg.



Step 4

Place the umbrella support brace onto the table support braces. Measure carefully to align it with the umbrella hole on the table top. Fasten with (4) 2" screws, 2 on each side.



Step 5

Your table is now complete.

Thank you for purchasing from Wildridge.