


#### Required Tools:

- Mallet/Non Marring Hammer (Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive Bit
- 1/2" and 7/16" Wrench or Socket

#### Parts:

- A = (1) Backrest
- B = (1) Seat
- C = (1) Right Facing Armrest
- D = (1) Left Facing Armrest





#### Hardware:

- (10) 2 1/2" Screws
- (1) Aluminum Angle Iron
- (4) 1/4" x 2 3/4" Bolts
- (4) 1/4" Washers
- (4) 1/4" Nylon Locknuts
- (4) 5/16" x 4" Eye Bolts
- (4) 5/16" Flange Nuts
- (4) 5/16" Washers
- (4) 5/16" Nylon Locknuts
- (4) Connector Links
- Swing Chains




#### Step 1

Mount the backrest (A) onto the seat (B). On the back side of the swing, fasten (3) 2 1/2" screws through the pre-drilled holes, as shown (pictured above), then place the aluminum angle iron as shown (pictured right), and fasten with (3) 2 1/2" screws through holes in angle iron.



#### Step 2

Lay the swing on its right side and place the left facing arm rest (C) as pictured. Slide (2) 1/4" x 2 3/4" bolts through the holes from the outside, through the armrest, and through the seat, and add a 1/4" washer and 1/4" nylon locknut, one per bolt. Next, fasten the front apron board to the armrest with (2) 2 1/2" screws as shown. Repeat with right facing armrest (D) and apron board on the other side.



#### Step 3

Thread a 5/16" flange nut onto a 5/16" x 4" eye bolt with the flange turned away from the eye and as far as the thread allows, and feed it through the pre-drilled hole on the back of the armrest and add (1) 5/16" washer and (1) 5/16" nylon locknut. Do the same on the front of the armrest. Repeat with remaining two eye bolts, etc. on the other end of the swing.



#### Step 4

Using the (4) connector links, attach the chains to eye bolts. Your swing is now complete.

*Thank you for purchasing from Wildridge.*