

Required Tools:


- Mallet/Non Marring Hammer (Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive Bit
- 7/16" Wrench or Socket

Hardware:

- (4) 1/4" x 2 1/2" Bolts
- (6) 1/4" Flange Nuts
- (4) 2 1/2" Screws
- (8) 1 1/4" Screws
- (2) 1/4" x 2" Bolts

Parts:

- A = (1) Backrest
- B = (1) Chair Seat
- C = (1) Right Leg
- D = (1) Left Leg
- E = (1) Right Armrest
- F = (1) Left Armrest



Step 1

Place the backrest (A) onto the chair seat (B) as shown.



Step 2

Space the backrest and the last slat on the chair seat the same distance apart as what the other chair slats are, then making sure the backrest and seat are flush on the sides, fasten the backrest to the seat with (4) 2 1/2" screws, two on each side of the chair.



Step 3

Lay the backrest/seat assembly onto its side as shown. Place the right leg (C) onto the side. Tap (1) 1/4" x 2 1/2" bolt through each of the holes in the leg and seat, add (2) 1/4" flange nuts but do not tighten completely. Repeat with the left leg (D) on the other side of the chair.



Step 4
Place the right (E) and left (F) arm rest into position as shown above. For each armrest tap (1) 1/4" x 2" bolt through the hole in the armrest and backrest, then add (1) 1/4" flange nut to each bolt. Do not tighten completely.



Step 5
To space an armrest on the leg support correctly, measure 3/4" in from the leg support to the inside of the armrest as pictured right, then from the underside as pictured above, fasten the armrest to the leg support with (4) 1 1/4" screws through the holes provided. Repeat with the other armrest.



Step 6
Making sure the chair is level, go back through and tighten all the flange nuts. Your chair is complete.... enjoy!
Thank you for purchasing from Wildridge.