



Required Tools:

- Mallet/Non Marring Hammer (Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive bit
- 7/16" Wrench or Socket

Hardware:

- (8) 2 1/2" Screws
- (8) 1/4" x 3 1/2" Bolts
- (8) 1/4" Flange Nuts

Parts:

- A = (1) Table Top
- B = (4) Legs
- C = (2) Shelves



Step 1

Lay table top (A) upside down on a soft surface and place the legs (B) in place, butting them up against the corner of the two stretchers, making sure all countersink holes in the legs are facing towards the outside. Fasten with (2) 2 1/2" screws per leg.



Step 2

Attach one of the shelves as shown (C), with (4) 1/4" x 3 1/2" bolts and (4) 1/4" flange nuts, one per leg. Repeat with the other shelf (not shown).



Your three-shelf side table is now complete.

Thank you for purchasing from Wildridge.