

#### Required Tools:


- Mallet/Non Marring Hammer (Do not use Metal Headed Hammer)
- Cordless Drill
- #2 Square Drive Bit
- 7/16" Wrench or Socket

#### Hardware:

- (8) 1/4" x 2-1/2" Bolts
- (10) 1/4" Flange Nuts
- (10) 2" Screws
- (6) 1 1/4" Screws
- (2) 1/4" x 2" Bolts

#### Parts:


- A = (1) Seat
- B = (2) Front Legs
- C = (2) Back Legs
- D = (1) Back
- E = (2) Armrests



#### Step 1

Lay seat (A) on side and attach front leg (B) and back leg (C) as shown with (4) 1/4x2-1/2" bolts and (4) 1/4" flange nuts (2 per leg).

**Note:** Be sure to position front leg (B) as shown with arm block on top pointing away from seat. Repeat on other side.




#### Step 2

Now position back (D) on back legs as shown and fasten with (6) 2" screws (3 per side).



#### Step 3

Fasten armrests (E) to chair with (2) 1/4"x2" bolts and (2) 1/4" flange nuts in back (1 per arm) and (6) 1 1/4" screws (3 per arm) in front from bottom up through arm blocks and holes provided. Divide space evenly on each side.



#### Step 4

Flip chair upside down. For added strength add (4) 2" screws on inside of front legs, (2) screws per leg.



Your chair is now complete.

*Thank you for purchasing from Wildridge.*