

Assembly Instructions:

Sunrise Thicket Side Table

Parts List:
1 - Table Top
1 - Shelf
2 - Legs

Hardware:
8 – 3½” Bolts
1 - Allen Wrench

Step 1

Set the table legs upright with the 2x2 braces turned toward the inside. The ends of the legs with the predrilled holes need to be turned up. Place the shelf between the legs on top of the 2x2 braces. Put 4 bolts through the predrilled holes in the shelf and turn into the threaded inserts in the braces. Tighten with the Allen wrench. (See photos 1 & 2.)




photo 1



photo 2

Step 2

Place the table top upside down on a clean surface. Now take the leg assembly and flip upside down and place on the table top. Align the 4 holes in the legs with the threaded inserts in the 2x2 braces on the table top. Put the remaining 4 bolts through the legs and turn into the inserts. Tighten with the Allen wrench. (See photos 3 & 4.)



photo 3




photo 4