



WATERPROOFING

# SOPRASEAL<sup>®</sup> STICK 1100 T WALLS



## SELF-ADHESIVE AIR/VAPOUR BARRIER MEMBRANE



SOPRASEAL STICK 1100 T is a self-adhesive air/vapour barrier membrane for walls composed of SBS modified bitumen and a tri-laminate woven polyethylene facer. It is also used as masonry and through-wall flashing membrane as well as waterproofing membrane at openings and transitions.

- Excellent adhesion to various substrates
- Ideal for sprayed polyurethane foam insulation
- Easy, fast and economical to install
- Self-sealing membrane ensuring continuous waterproofing

### SURFACE PREPARATION

Substrates must be clean and dry, primed with SOPRASEAL STICK PRIMER, ELASTOCOL STICK ZERO or ELASTOCOL STICK H<sub>2</sub>O to ensure better adhesion.

### COMPLEMENTARY PRODUCTS

**SOPRASEAL STICK PRIMER,  
ELASTOCOL STICK ZERO &  
ELASTOCOL STICK H<sub>2</sub>O**

Used to prepare surfaces before the installation of self-adhesive membranes.

**SOPRASEAL STICK FLASHPRO  
SOPRASEAL STICK FLASHPRO HT  
SOPRASEAL STICK 1100T in cut rolls**

**SOPRASEAL SEALANT**

Designed to seal wall details.

### SOPRASEAL STICK 1100 T

THICKNESS	1.0 mm (40 mil)
DIMENSIONS	0.91 x 22.9 m (3 x 75 ft)
SURFACE	Tri-laminate woven polyethylene
UNDERFACE	Silicone release paper



SOPREMA.US • 1.800.356.3521

SOPREMA.CA • 1.877.MAMMOUTH

## INSTALLATION INSTRUCTIONS

1



Prime the substrate with SOPRASEAL STICK PRIMER, ELASTOCOL STICK ZERO or ELASTOCOL STICK H<sub>2</sub>O.

2



Peel off the top portion of the silicone release paper and adhere the membrane to the substrate, making sure the membrane is well aligned.

3



Gradually peel off the remaining silicone release paper, making sure the membrane adheres completely to avoid air pockets and wrinkles.

4



Use a roller to apply pressure over the entire surface of the membrane to ensure uniform adhesion to substrate.

5



Use SOPRASEAL SEALANT to seal around details, reverse laps, critical areas and window openings.

If you have any questions about this product or its installation, please contact your SOPREMA representative.



SOPREMA.US • 1.800.356.3521

SOPREMA.CA • 1.877.MAMMOUTH