

Operating Instructions

EN | 3S-1989 - 3sixT Elfin Plus 10W Wireless Charger with AC - Black

INCLUSIONS: Elfin 10W Wireless Charger QC3.0 Wall Charger USB-A to Micro USB Cable 3six Global Warranty Document

WARNINGS

• Read all instructions and warnings before using this product. Improper use of this product may result in product damage, excessive heat, toxic fumes, fire or explosion, for which damages you ("Purchaser") and not 3sixT ("Manufacturer") are responsible.

• Do not store the accessory in a high-temperature environment, including heat caused by intense sunlight or other forms of heat (heaters etc.).

• Do not place the device in fire or other extremely hot environments.

• Do not disassemble or modify this accessory in any manner.

• Do not attempt to power this device using any other method than as instructed explicitly in this user guide.

• This accessory is intended for adults and not minors. Failure not to follow these warnings is the sole responsibility of the purchaser, who agrees to indemnify the Manufacturer ("3sixT") for any unintended use/misuse by a minor.


• All products must pass through a thorough quality inspection at the time of manufacture. However, if you find that your device is excessively hot, is found to be deformed outside its regular appearance or is emitting smoke, immediately stop using the device and contact 3sixT.

© 2020 3sixT. All rights reserved. 23/136 Keys Road, Cheltenham VIC 3192 Australia.

MADE IN CHINA




www.3sixtgear.com or visit www.3sixtgear.com/support





NAME PARTS

- 1. LED indicator
- 2. Micro-USB input
- 3. Wireless charging face
- 4. Air vents
- 5. Wall Charger USB Port



Note Well:

- For optimal performance use the included QC3.0 wall charger.
- Qi wireless charging generates heat within the device being charged and the accessory doing the charging. This is a normal byproduct of charging devices wirelessley.



www.3sixtgear.com or visit www.3sixtgear.com/support





OPERATION

Charging your Device

1. Locate the provided USB-A to Micro USB Cable

2. Locate the Micro USB input (2) on the Elfin Charger

3. Make sure that the Micro USB input (2) is clear of obstruction (dirt/dust etc).

4. Plug the USB-A end of the cable into the included wall charger (5), making sure its fully connected (do not push with excessive force).

5. Plug the Micro USB connector end of the cable into the Micro-USB input on the Elfin Charger (2), making sure its fully connected (do not push with excessive force).

6. Turn power on at the power source. The Elfin Chargers LED indicator (1) will blink green three times briefly and turn off. This indicates that the Elfin Charger accessory is ready to be used.

7. Place your compatible device centrally on the wireless charging face (3) and charging will commence automatically. The LED indicator will remain green as your device is being charged.

8. To stop charging simply remove your device from the Elfin Charger and charging will automatically discontinue. The accessory will then return to standby mode ready to charge.

Foreign Object Detection (FOD)

1. When an object other than a Qi wireless enabled device is added to the wireless charging face (3) of the Elfin Charger the LED indicator will flash green on/off quickly in succession.

2. No charging will occur in this state.

3. To remedy this, simply remove the foreign object from the Elfin charger and it will revert back into standby mode.

Understanding the LEDs

| Charging |
|--|
| Powering up cycle |
| Error / Foreign Object Detection (FOD) |
| Standby mode |
| |

SPECIFICATIONS

| Item/Model Number: | 3S-1989 (Black) |
|---------------------------------|---------------------|
| Input: | Micro USB 9V/2A MAX |
| Output: | 5W/7.5W/10W |
| Launch Distance: | ≤7mm |
| Over Current Protection: | Yes |
| Over Voltage Protection: | Yes |
| FOD Protection: | Yes |
| Working Temp: | –10° to 60 °C |
| Product Dimensions: | 10mmx75mmx75mm |
| Working Temp: | -10° to 60 °C |



www.3sixtgear.com or visit www.3sixtgear.com/support

