



SSV WORKS, 201 N. Rice Ave Unit A, Oxnard, CA 93030
www.SSVworks.com | Phone: 818-991-1778 | Fax: 866-293-6751

RZ5-DF65

2019+ Polaris RZR Pro XP

6.5" Front Door Speaker Pods

WARRANTY INFORMATION:

All SSV Works enclosures are covered by a limited lifetime warranty against defects in material or workmanship. All SSV Works Electronics are covered by a limited 1 year warranty against defects in material or workmanship. All Kicker Speakers are covered by a limited 1 year warranty against defects in material or workmanship. All Kicker Amplifiers are covered by a limited 2 year warranty against defects in material or workmanship. Labor for replacement of defective components is not covered. Contact SSV Works for further warranty information.



Please read and understand these instructions completely before installation to avoid possible injury, or damage to the accessory or vehicle.

TOOLS NEEDED FOR INSTALLATION

- T25, T30, T40 Torx Driver - 10mm wrench


PARTS LIST IMAGES



1. RZ5-DF65 Enclosure (pair)



2. M6 x 14mm Screws x 8



3. M6 Washers x 16




4. M6 x 16mm Screws & M6 Nuts x 4




5. Mounting Brackets x 2



A. Fasten the mounting brackets to the enclosures with (2) T30 M6x1.0x14mm screws and washers.




B. The mounting brackets are side specific. To verify the correct orientation of the bracket, follow the outline in the diagram above.



C. Remove the (11) T40 torx screws and (2) T25 Torx screws from the door and set the door skin aside (Step C1). Put the pod in place on inside of the door. Loosely fasten (2) T30 M6x1.0x14mm torx screw and washers through the top of the door frame and into the RZ5-DF65 (Step C2 & C3).




RZ5-DF65



E. Insert (2) T30 M6x1.0x16mm torx screws and washers through the front of the enclosure mounting bracket and secure to the door frame with (2) 10mm M6 nuts and washers. Tighten hardware once it has all been installed.

WIRING INSTRUCTIONS



For proper sound, ensure the speaker polarity is correct connect the "+" to the "+" and the "-" to the "-" from the speaker wire to the amplifier. If using with an SSV Works complete system refer to the amplifier wiring instructions for more detailed wiring information.



Installation is now complete. Re-assemble all door factory panels.