



SSV WORKS, 201 N. Rice Ave Unit A, Oxnard, CA 93030
 www.SSVworks.com | Phone: 818-991-1778 | Fax: 866-293-6751

X3-F4

2017+ Can-Am Maverick x3 & x3 Max 4" Speaker Dash Pods

WARRANTY INFORMATION:

All SSV Works enclosures are covered by a limited lifetime warranty against defects in material or workmanship. All SSV Works Electronics are covered by a limited 1 year warranty against defects in material or workmanship. All SSV Works Speakers are covered by a limited 1 year warranty against defects in material or workmanship. Labor for replacement of defective components is not covered. Contact SSV Works for further warranty information.



Please read and understand these instructions completely before installation to avoid possible injury, or damage to the accessory or vehicle.

TOOLS NEEDED FOR INSTALLATION

- T-30 Torx Driver
- 10mm Wrench or Ratchet
- Drill 1/4" Drill bit
- Utility Knife

PARTS LIST

- | | |
|------------------------------|-------------------------|
| 1. X3-F4 Enclosures (1 pair) | 4. M6 x 25mm Screws x 2 |
| 2. Acoustic Lens (1 pair) | 5. M6 Washers x 6 |
| 3. M6 x 1.0 Screws x 4 | 6. 10mm Nut x 2 |

PARTS LIST IMAGES



1. X3-F4 Enclosures (1 pair)



2. Acoustic Lens (1 pair)



3. M6 x 1.0 Screws x 4



4. M6 x 25mm Screws x 2



5. M6 Washers x 6




6. 10mm Nut x 2



A. Remove the top dash panels on the driver (7 screws with 2 clips) and passenger side (5 screws with 2 clips).



B. Pry off the 4 clips on the base under the empty space for the speaker




C1



C2

C. Using a utility knife, cut off the 4 tabs flush to the panel



D1



D2

D. Drill a hole using a 1/4" drill bit at the factory dimple marks (as shown above) on the outside dash panel around the speaker grille.



E. Place the acoustic lens on top of the factory grille, line up the holes and insert the 2 top M6x1.0 (shorter) screws and washers.



F. Place the speaker pod under the dash panel and line up the holes on the speaker pod with the 2 top screws and loosely mount the pod to the dash panel.




G. Insert the M6x25mm screw by pushing it through the acoustic lens, dash panel and speaker pod. Tightly screw down using the washer and 10mm nut. Now tighten the previous 2 M6x1.0 screws.



H. Route the speaker wire away from any moving parts and any sharp metal, then connect to the amplifier. Connecting the X3-D4 using the pre-installed, two-pin connector will require an optional SSV Works plug-&-play harness (WP-H1149 - sold separately). If you are not using the WP-H1149 harness, simply cut off the two-pin connector and follow the wiring instruction below.

I Installation complete. Reassemble the dash panel.

WIRING INSTRUCTIONS



For proper sound, ensure the speaker polarity is correct connect the "+" to the "+" and the "-" to the "-" from the speaker wire to the amplifier. If using with an SSV Works complete system refer to the amplifier wiring instructions for more detailed wiring information.