

- · Ladder lets young children climb onto trampoline.
- Trampolines not for children under 6 years.
- Do not use ladder if children under six might be nearby.
- Remove when trampoline is not in use.
- User weight limit 242 lbs (110 kgs).

AWARNING

· Adult assembly required.

• CHOKING HAZARD- Small parts not for children under 6 years. • Read the assembly, care, maintenance, and use instructions in this manual prior to assembling and using this equipment. Save this manual for future reference.

CARE AND MAINTENANCE

If your ladder becomes dirty, spray with water to clean. Do not allow use of the ladder until completely dry. Check all hardware before each use. Tighten any bolts and nuts that have become loose. If you notice any broken parts, put your trampoline ladder away until it can be fixed.

The terms and conditions of North Trampoline's general warranty can be accessed on www.northtrampoline.com/ warranties as well as on the individual retailer's website.

North Trampoline, INC. C / O THORELLI AND ASSOCIATES 70 West Madison ST., STE 5750 Chicago, IL 60602

Item no: NA100020



