

# Speed Demon™ V2.0, Speed Freak™ V2.0, Speed Racer™ V2.0 Instructions

**thinkTANK** photo  
Be Ready "Before The Moment"™

## USE AS A SHOULDER BAG



**Step 1:** Tuck the waist belt into the zippered openings on either side of the back of your Speed Bag.



**Step 2:** Attach the metal snap hooks on the shoulder strap to the webbing attachment points on your Speed Bag.



The non-slip grip will prevent the shoulder strap from slipping.

## CONVERT TO A BELT PACK



**Step 1:** Remove the waist belt straps from the zippered openings on either side of the back of your Speed Bag.




**Step 2:** Wear the shoulder strap with the belt for additional comfort and support.



The integrated belt features a Modular rail for attaching additional Think Tank Photo Modular components.

## BUCKLE STOPS



The "Buckle Stops" are the metal secondary buckles on either side of the main buckle which prevent the belt from loosening.



After adjusting the belt to a comfortable size, loosen the webbing threaded through the Buckle Stop. Then slide the Buckle Stop close to the main buckle.



Positioning the Buckle Stops one to two inches away from the main buckle allows the belt to be loosened or tightened as needed. Keeping the Buckle Stops directly against both sides of the main buckle prevents the belt from loosening over time.