


### SINGLE PHASE WIRING DIAGRAM

### NOT FOR RESIDENTIAL USE




**WARNING:** FOR CONTINUED PROTECTION AGAINST FIRE, REPLACE FUSES ONLY WITH THE SAME TYPE AND RATING




### SINGLE PHASE WIRING DIAGRAM

### TROUBLESHOOTING LED's

<b>STB ENABLE</b>	ON = STB ENABLED	OFF = STB DISABLED
<b>+ 24 VOLTS DC</b>	ON = POWER AVAILABLE	OFF = CHECK AC POWER SUPPLY. CHECK FUSES




### EXTERNAL WIRING DIAGRAM



### THREE PHASE WIRING DIAGRAM

NOT FOR RESIDENTIAL USE



**WARNING:** FOR CONTINUED PROTECTION AGAINST FIRE, REPLACE FUSES ONLY WITH THE SAME TYPE AND RATING



COMMERCIAL LINE


[www.GenieCompany.com/commercial](http://www.GenieCompany.com/commercial) | 800.843.4084

©2012 The Genie Company


### THREE PHASE WIRING DIAGRAM

### TROUBLESHOOTING LED's

<b>STB ENABLE</b>	ON = STB ENABLED	OFF = STB DISABLED
<b>+ 24 VOLTS DC</b>	ON = POWER AVAILABLE	OFF = CHECK AC POWER SUPPLY. CHECK FUSES



### EXTERNAL WIRING DIAGRAM




P/N 111281.0001



### 575 VOLT PHASE WIRING DIAGRAM

NOT FOR RESIDENTIAL USE



**WARNING:** FOR CONTINUED PROTECTION AGAINST FIRE, REPLACE FUSES ONLY WITH THE SAME TYPE AND RATING



COMMERCIAL LINE


[www.GenieCompany.com/commercial](http://www.GenieCompany.com/commercial) | 800.843.4084

©2012 The Genie Company


### 575 VOLT PHASE WIRING DIAGRAM

#### TROUBLESHOOTING LED's

<b>STB ENABLE</b>	ON = STB ENABLED	OFF = STB DISABLED
<b>+ 24 VOLTS DC</b>	ON = POWER AVAILABLE	OFF = CHECK AC POWER SUPPLY. CHECK FUSES



#### EXTERNAL WIRING DIAGRAM



P/N 111379.0001

