


EMBLASER CORE

Kit Rev. 1.0

User Assembly Manual



English

IMPORTANT



SAFETY GLASSES MUST BE USED

The Emblaser Core contains a Class 4 laser device. This device could cause damage to your eyesight or blindness.

Always wear your safety glasses when operating your machine.

IMPORTANT



BANNED MATERIALS

**PVC, VINYL, ABS,
FIBERGLASS, COATED CARBON FIBER,
ANY MATERIAL CONTAINING CHLORINE**

Using these materials within your machine will produce extremely toxic fumes, leading to severe health issues and machine damage.

If you do not know what your material contains, **DO NOT USE IT.**

FOR YOUR SAFETY

To prevent damage to your Emblaser Device or injury to yourself or to others, read the following safety precautions carefully. Keep these safety instructions where all those who use the product will read them.



WARNINGS

Sharp!

Take care of sharp edges and points when handling all parts in this kit (including the acrylic frame).

Crack!

Take care when handling all parts in this kit, some parts will be fragile and prone to breakage until assembled.

Take care when tightening fasteners. Over tightened fasteners can damage the parts around them.

Do not use in wet surroundings

Water and electricity are a dangerous combination. Ensure your workspace is dry and not subject to potential wet conditions.

Do not operate the Emblaser Device if damaged

Damage to any part of the Emblaser Device could compromise its safety and cause injury. If any part of the Emblaser Device is damaged, contact your reseller or Darkly Labs directly before operation.

- Darkly Digital Pty Ltd (Darkly Labs) reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- While every effort has been made to ensure that the information in this manual is accurate and complete, we would appreciate it were you to bring any errors or omissions to the attention of the Darkly Labs (info@darklylabs.com)

Ensure proper supervision of children and impaired users

The Emblaser Device is not intended for children under the age of 15 years. Children under the age of 15 years should be supervised to ensure they do not play with the Emblaser Device.

Teenagers aged between 15 and 18 years can use the Emblaser with the consent and/or assistance of their parents or persons who have parental authority over them. The Emblaser Device is not intended to be used by persons (including children) with reduced physical, sensory or mental capabilities, unless they have been given supervision or instruction concerning use of the Emblaser Device by a person responsible for their safety.

GETTING STARTED

Preparation

A medium size table should be enough space to construct your Emblaser Core. Allow yourself 2-3 hours to complete the kit assembly.

Use powered drivers at your own risk!

We recommend using hand tools supplied, as some parts may be damaged by overtightening.

Whats in the Box


Box 1 Getting Started card, LightBurn license & assembly components.

Box 2: Contains the bulk of the assembly components.

Box 3: Contains optional extras.

Box 4: Contains the linear rails and driver board cover.

Underneath these four packages are the Base Plate and Acrylic Panels.




Running into trouble?

If you get stuck or have any questions, comments or feedback, please contact us at: support@darklylabs.com

CONTENTS Misc. Parts

- 1x Power Supply
- 1x USB cable
- 1x Getting Started Card
- 1x Safety Glasses
- 4x Cutting Mats
- 1x Lens cleaning liquid dispenser
- 1x Magnifier

PARTS STAGE 1 Frame Assembly



1x Top Panel




1x Front Panel




1x Rear Panel




2x Side Panel



8x Corner Bracket



4x Cable Management Clip



6x Panel Bracket



36x M3 Washer




36x M3x12mm Screw




24x M3 Nut

PARTS


STAGE 2 Gantry Assembly



1x Homing Trigger




2x Belt




1x Belt Hub




4x Rail Bracket



2x Motor Bracket



2x Motor



2x Motor Pulleys



18x M3x30mm Screw



18x M3 Washer



10x M3 Nut



4x Shoulder Bolt




4x Spacer




4x M5 Lock Nut




4x M5 Washer



8x Flanged Bearings



1x Laser Carriage
(contains only 3
linear bearings)




2x Gantry Carriage




2x Long Gantry Rail
2x Short Gantry Rail

PARTS


STAGE 3 Driver Board



1x Driver Board Cover
& Flexible Cable



1x Driver Board



1x Laser Unit




1x M3x12mm Screw




4x M3x8mm Screws

PARTS


STAGE 4 Button PCB




1x Button PCB



1x Button PCB Cover



1x Enable Button



1x Power Button



1x Ribbon Cable



2x M3x12mm Screw




2x M3 Washer




2x M3 Nut


PARTS

 STAGE 5 Controller Board

1x Controller Board



1x Controller Board Cover



2x Motor Cables



4x Standoff



4x M3x12mm Screw




4x M3 Washer

PARTS

 STAGE 6 Assembly Completion

1x Base Plate



10x Rubber Feet



8x M3x12mm Screw




8x M3 Washer



8x M3 Nut

PARTS


Air Assist Accessory (OPTIONAL)



1x Air Assist Pump



1x Air Assist Hose



3x Air Assist Hose Clips



2x M4x6mm Screw



2x M4 Washer

PARTS

Workspace Camera Accessory (OPTIONAL)



1x Workspace Camera



2x M3x12mm Screw



2x M3 Washer



2x M3 Nut

STAGE 1 FRAME ASSEMBLY

Lay out the parts listed below. Refer to the 'PARTS Stage 1' section.

- Top Panel
- 2x Side Panel
- Front Panel
- Rear Panel
- **Remove protective film from panels before starting construction**


- 8x Corner Bracket
- 6x Wall Bracket
- 4x Cable Management Clip
- 36x M3x12mm Screw
- 36x M3 Washer
- 24x M3 Nut

You will also need a **2.5mm Hex Tool**. (This and other tools can be found in Box 1 (Accessories).

Step 1.01


Attach 4x **Corner Brackets** to the **Rear Panel**.

Important: Keep the feature indicated in green to the left.




Step 1.02

Place the **Front Panel** on the table with the logo facing down.
Attach 4x **Corner Brackets** to the **Front Panel**.




Step 1.03

Attach the two **Side Panels**.



Step 1.04



Place the 4x **Cable Management Clips** in the recesses on the **Rear Panel**.



Step 1.05


Attach the **Top Panel**.

Important: Keep the holes indicated in green to the right.




Step 1.06

Attach the **Panel Brackets** to the **Front, Rear and Side Panels**. . You do not need nuts for this step.




M3 x 12mm SCREW

M3 WASHER



Attach the **Panel Brackets** to the **Top Panel**.



STAGE 2 GANTRY ASSEMBLY

Lay out the parts listed below. Refer to the 'PARTS Stage 2' section.

- Homing Trigger
- 2x Belts
- Belt Hub
- 4x Rail Bracket
- 2x Motor Bracket
- 2x Motors
- 2x Motor Pulleys
- 18x M3x30mm Screws
- 18x M3 Washers
- 10x M3 Nuts
- 4x Shoulder Bolts
- 4x M5 Lock Nuts
- 4x M5 Washer
- 8x Flanged Bearings
- 4x Spacers
- 2x Gantry Carriage
- Laser Carriage


In addition, lay out the parts listed below.

- 2x Long Rails
- 2x Short Rails

You will also need a **2.0mm Hex Tool**, a **2.5mm Hex Tool** and a **3.0mm Hex Tool**.

Step 2.01


Flip the **Frame Assembly** over and rest it on a pair of the small boxes included in the packaging.




Step 2.02

Place a **Motor Pulley** onto one of the **Motors**. Position the small screw in the **Motor Pulley** over the flat face of the **Motor** shaft and fasten using the **2.0mm Hex Tool**.

Important: Leave approx. 0.5mm gap between the **Motor Pulley** and the **Motor**.





Place the second **Motor Pulley** upside down over the shaft of the remaining **Motor**. Repeat the previous step. The two **Motors** should now look like the ones in the image below.





Step 2.03

Attach the **Motors** to the underside of the **Top Panel** with the **Motor Brackets**.
Make sure the **Motor** connectors are facing the centre of the machine.
Take note of **Motor Bracket** orientation.





Step 2.04

Attach two **Rail Brackets** to the underside of the **Top Panel**. Make sure the arrow on the **Rail Bracket** points towards the **Top Panel**.



Step 2.05


Attach the **Homing Trigger** to the underside of the **Top Panel**.




Step 2.06

Assemble the four **Idle Pulleys**.


**LOWER POSITION
IDLE PULLEY**




**UPPER POSITION
IDLE PULLEY**



**LOWER POSITION
IDLE PULLEY**




**UPPER POSITION
IDLE PULLEY**




Step 2.07

Attach the **Idle Pulleys** to the underside of the **Top Panel**.




Important! Correct placement of UPPER and LOWER Idle Pulleys is critical to the function of your Emblaser device.




Step 2.08

Insert the two **Long Rails** into one of the **Gantry Carriages**.




Slide the **Laser Carriage** onto the two **Long Rails**.

Important! Orientate the Laser Carriage so its motor is at the bottom.




Attach remaining **Gantry Carriage**.




Step 2.09

Slide the **Laser Carriage** back and forth the motion should be smooth and constant. If it feels tight near the gantry carriages can adjust the tightness of the shoulder bolts in the **Gantry Carriages** accordingly.




Insert the two **Short Rails** into the **Gantry Carriages** and attach the remaining **Rail Brackets** as shown.




Step 2.10

Pick up the **assembly** from the previous step and place it in the **Frame Assembly** as shown. Take note of arrow direction in the diagram.





Insert the **Gantry Assembly** into the **Rail Mounts** attached to the **Top Panel**.




Step 2.11

Attach the final two **Rail Brackets** to the underside of the **Top Panel**.




Step 2.12

Keep the **Frame Assembly** upside down and held up by the small boxes.
The **Front, Rear and Side Panels** have been hidden in the following illustrations.




This is by far the trickiest part of the kit to assemble but don't worry!
Here is a list which guarantee success.


- Take note of which way the belt teeth are facing in the diagrams.
- Take note of which pulleys are specified in each diagram.
- If a belt gets twisted or tangled, don't panic! Pull it out, untwist it and try again.
- Take your time.



The diagrams below highlights the position of **Belt Pulleys**.
There are Upper Position pulleys and Lower Position pulleys.




- LOWER POSITION BELT PULLEYS
- UPPER POSITION BELT PULLEYS




Step 2.13

Thread one end of a **Belt** through the **Gantry Carriage** indicated in the diagram.




The teeth of the **Belt** should be touching the **Flanged Bearing**.




Step 2.14

The front of the **Belt Hub** (indicated by the circle) always faces the **Front Panel**.




Insert the end of the **Belt** into the channel in the bottom of the **Belt Hub** next to the **GREEN** tab as shown in the image below.




Step 2.15


Route the **Belt** around the two Lower Position Idle Pulleys as shown.




Step 2.16




Pass the **Belt** straight through the **Gantry Carriage** and around the **Motor Pulley**.



Step 2.17




Route the **Belt** behind lower position pulley in the **Gantry Carriage**.




Step 2.18


Bring the **Belt** around behind the **Laser Carriage**.




Move the **Gantry Carriages** to the front of the machine so that both are touching the **Top Panel**.




Pull the belt tight. This should cause the left hand side **Gantry Carriage** to pull away from the **Top Panel**.



Apply just enough tension to the belt so the gap between the left hand side **Gantry Carriage** and the **Top Panel** is approximately 5mm.



Remove the **Green Tab** from the **Belt Hub** and insert the loose end of the **Belt** into that channel.




Check the position of the **Gantry Carriages** again. When the left hand **Gantry Carriage** is touching the **Top Panel**, the right hand **Gantry Carriage** should be 5mm away from the **Top Panel**.


Note: The **Gantry Assembly** will now be on an angle, this is corrected when tensioning the second **Belt**.

Step 2.19

Thread one end of the second **Belt** through the **Gantry Carriage** indicated in the diagram.




The teeth of the **Belt** should be touching the **Flanged Bearing**.



Step 2.20


Insert the belt into the channel in the top of the **Belt Hub**.

Use the empty channel, NOT the channel containing the yellow tab.




Step 2.21


Route the **Belt** around the two Upper Position Idle Pulleys as shown.




Step 2.22




Pass the **Belt** through the **Gantry Carriage** and around the **Motor Pulley**.




Step 2.23



Route the **Belt** behind lower position pulley in the **Gantry Carriage**.




Step 2.24




Step 2.25

Move the **Gantry Carriages** to the front of the machine.

If the first belt has been tensioned correctly, the left **Gantry Carriage** will sit 5mm back from the **Top Panel** when the right **Gantry Carriage** is touching the **Top Panel**.




Pull the belt tight. This should cause the left hand side **Gantry Carriage** to get closer to the **Top Panel**.




Apply just enough tension to the belt to remove the gap between the left hand side **Gantry Carriage** and the **Top Panel**.

Remove the yellow belt tab and and press the **Belt** into the **Belt Hub** as shown in the diagram.




Step 2.26

Take this opportunity to check the **Belts** for twists and to make sure the correct pulleys are used for each **Belt** and that the gantry carriages meet the front of the **Top Panel** without any gaps.



Flip the **Frame Assembly** back over onto its feet and test one last time that the **Gantry Carriages** meet the **Top Panel** at the same time.




IMPORTANT: If the **Gantry** is not square, your designs will not be square.
If the **Gantry** is not square, your machine may fail to home correctly.

The **Gantry** is not square if the **Gantry Carriages** do not touch the **Top Panel** at the same time when pushed backwards and forwards. Take a moment to redo the **Belts** now.

Step 2.27

Insert **Belt Hub** into the **Laser Carriage**.



STAGE 3 DRIVER BOARD


Lay out the parts listed below. Refer to the 'PARTS Stage 3' section.

- Driver Board Cover & Flexible Cable.
- Driver Board
- 1x M3x12mm Screws
- 4x M3x8mm Screws
- Laser Unit

You will also need a **2.5mm Hex Tool**.

Step 3.01


Attach the Laser Unit to the Laser Carriage.







Step 3.02

Familiarise yourself with the **Driver Board Cover** using the diagrams below.

DRIVER BOARD FLEXIBLE CABLE



CABLE MANAGEMENT FLAP




LATCHES

Step 3.03

Place the **Driver Board** over the **Driver Board Cover** and attach to the **Laser Carriage**.


Note: Don't allow any cables to be trapped under the **Driver Board** or the **Cover**.




Step 3.04

Route the **Laser Unit** cables around the side of the **Laser Carriage** and under the Cable Management Flap illustrated in Step 3.02.


Important: Cables must pass around the side of the **Laser Carriage**, not over the top.




Connect the cables to the **Driver Board** sockets indicated in the diagram below.




Step 3.07




Fold the **Driver Board Cover** as shown in the diagram.



Connect the **Flexible Cable** to the **Driver Board** connector socket indicated in the diagram below.



Clip In Latches.



STAGE 4 BUTTON PCB


Lay out the parts listed below. Refer to the 'PARTS Stage 4' section.

- Button PCB
- Button PCB Cover
- Enable Button
- Power Button
- Ribbon Cable
- 2x M3x12mm Screws
- 2x M3 Washer
- 2x M3 Nut

You will also need a **2.5mm Hex Tool**.



Step 4.01

Create the **Button PCB Cover** along the highlighted lines.
Insert the **Button PCB**.




Step 4.02

Turn the Frame Assembly upside down. Use the small boxes again to raise it off your table.




Step 4.03

Attach the **Button PCB Cover** to the **Rear Panel**.




Step 4.04


Completely remove the hexagonal nuts from the **Power Button** and the **Enable Button**.



Insert the buttons into the indicated holes in the Top Panel.
Return the hexagonal nuts to the buttons and tighten by hand.



Connect the **Power and Enable Buttons** to the **Button PCB**.



STAGE 5 CONTROLLER BOARD

Lay out the parts listed below. Refer to the 'PARTS Stage 5' section.

- Controller Board ****Do not remove from anti-static bag until instructed****
- Controller Board Cover
- 2x Motor Cables
- 3x Support Strip Clips
- 4x M3x12 Screws
- 4x M3 Washer
- 4x Standoff

You will also need a **2.5mm Hex Tool**.


This stage of the assembly has components that are sensitive to damage from static.



Please read and follow these steps:

- Only handle the controller board by its edges.
- Only remove the controller board from its bag when you are ready to install it.
- Do not walk around with the controller board.
- Avoid handing the controller board from one person to another.



Step 5.01

Familiarise yourself with the Controller Board Cover using the following diagrams.






When the **Controller Board Cover** is fully folded; the lines on the back face should be visible from the outside.



Step 5.02


Pull the **Driver Board Cover Tail** through the gap between the **Top Panel** and **Rear Panel**.



Pull the white flexible cable part of the **Driver Board Cover Tail** through the hole in the **Controller Board Cover**.


The black part of the tail should sit outside the **Controller Board Cover**.

Expose the adhesive on the black part of the tail and stick it between the lines on the Rear face.




Step 5.03


Pull the **Diver Board Cover** Tail back down through the **Top Panel** until the cover is resting on the top panel.




Attach the **Controller Board Cover** to the **Rear Panel**.



Step 5.04





Taking care not to put creases in the **flexible cable**, hold it up against the **Top Panel** to prevent it getting trapped underneath, then clip the **Controller Board** to the standoffs in the **Rear Panel**.



Step 5.06


Insert **flexible cable** into **Controller Board** socket indicated in the diagram below.

Note: To avoid damage, position **FFC** as squarely as possible to the connector before inserting.




Step 5.07


Move the ferrite rings on the **Motor Cables** all the way to the indicated connector.



Connect the **Motor Cables** to the **Motors** and the indicated sockets in the **Controller Board**.




Slip the loose cables into the **Cable Clips** to keep them tidy.




Step 5.08

Connect the **Ribbon Cable** to the **Button PCB** and to the indicated socket in the **Controller Board**.



Slip the loose cables into the **Cable Clips** to keep them tidy.



STAGE 6 ASSEMBLY COMPLETION

Lay out the parts listed below. Refer to the 'PARTS Stage 8' section.



- Base Plate.
- Rubber Feet. (10x)
- 8x M3x12mm Screws.
- 8x M3 Washers.
- 8x M3 nuts.

You will also need a **2.5mm Hex tool**.

Step 8.01

Close **Controller Board Cover**.


Tip: Manage free cables using **Cable Clips** in **Rear Panel**. Group excess cable inside **Controller Board Cover** before closing.



Step 8.02

Align **Base Plate** to the **Corner Brackets** making sure the holes indicated by the green arrow are in the orientation as shown.


Attach the **Base Plate** to the **Corner Brackets**.



M3 x 12mm SCREW


M3 WASHER

M3 NUT



Step 8.03

Attach the **Rubber Feet** to the **Base Plate** as shown below.



AIR-ASSIST ACCESSORY (OPTIONAL)

Only perform this stage if you have purchased the **Air-Assist accessory**.


Lay out the parts listed below. Refer to the 'PARTS Stage 6' section.

- Air assist pump
- Air Assist hose
- 3x Air Assist hose clips
- 2x M4x6mm screw
- 2x M4 washer


You will also need a **2.5mm Hex Tool**.

Step 01

Insert one end of the **Air-Assist Hose** through the **Top Panel** as indicated.
Pull the end of the **Air-Assist Hose** past the **Controller Board**.




Loop the **Air-Assist Hose** back under the **Controller Board** and out the left-hand side.




Step 02

Attach the end of **Air-Assist Hose** to the **OUTPUT** of the **Air Assist accessory**.




Step 03

Attach the Air-Assist pump to the baseplate using the two M3x6mm screws and washers provided.




Step 04

Connect **Air-Assist** cable to the **Controller Board** and **Air-Assist PCB**.




Step 05

Attach the additional rubber foot supplied with the Air-Assist Accessory to the base plate between the fasteners as indicated.




Step 06

Route the free end of the **Air-Assist Hose** through the **Driver Board Cover** as shown.




Step 07

Remove the **Aperture Nozzle Plug** and insert end of **Air-Assist Hose** into the **Aperture Nozzle**.




Step 08

Attach three **Air-Assist Hose Clips** in the positions shown below. The air-assist hose catch on the clips should face downwards.



Attach the air-assist hose into its clips.



WORKSPACE CAMERA ACCESSORY (OPTIONAL)

Only perform this stage if you have purchased the **Workspace Camera accessory**.


Lay out the parts listed below. Refer to the 'PARTS Stage 7' section.

- Workspace Camera
- 2x M3x12mm Screw
- 2x M3 Washer
- 2x M3 Nut

You will also need a **2.5mm Hex tool**.


Step 01

The Workspace Camera accessory attaches to the top panel as indicated below.




Step 02

Pull the **Workspace Camera** cable through slot in **Top Panel** as shown.





Attach Workspace Camera to the Top Panel as shown.



Step 03

Connect **Workspace Camera** cable to the **Controller Board** socket indicated.



CONGRATULATIONS!

You have completed assembling your Emblaser Core.

Your next step is to work through the User Manual. Go to this link to get started:

darklylabs.com/e2start

Technical support

If you need more information about the assembly or operation of your Emblaser Core, check the Help Centre:

darklylabs.com/help

Otherwise, please email us at:

support@darklylabs.com



Unit 3, 99-101 Western Ave, Westmeadows, 3049 Australia

info@darklylabs.com • www.darklylabs.com