




1. Install Lock Body      2. Install Drive Bar Cylinder      3. Mount Inside Plate




See template for door prep specifications




Note: Notch on cylinder must be in the 9 o'clock position when fully screwed into lock body.




4. Mount Outside Plate      5. Thread Key Cylinder      6. Tighten Drive Bar Cylinder



Install Key Cylinder by threading it clockwise onto lock body plate





Key Cylinder notch must be at the 3 o'clock position when fully screwed in lock body.



Tighten locking screw to engage notch on cylinder


7. Install Trim Plate      8. Install Door Jamb



Drill two 7/64" pilot holes


See template for door jamb prep specifications

1. Install Lock Body




See template for door prep specifications

2. Install Drive Bar Cylinder




Note: Notch on cylinder must be in the 9 o'clock position when fully screwed into lock body.

3. Mount Inside Plate




4. Mount Outside Plate and Thread Key Cylinder

Install Key Cylinder by threading it clockwise onto lock body plate




Key Cylinder notch must be at the 3 o'clock position when fully screwed in lock body.


5. Tighten Drive Bar Cylinder



6. Install Trim Plate



7. Install Door Jamb




Drill two 7/64" pilot holes


See template for door jamb prep specifications

1. Install Lock Body

2. Install Outside Plate





See template for door prep specifications




3. Install Inside Plate


4. Install Trim Plate




1. Install Lock Body




2. Hold Outside plate in place



3. Secure both inside & outside Plates




4. Install Trim Plates




Secure both inside and outside plates using machine screws (provided)

1. Install Lock Body



See template for door prep specifications


2. Install Drive Bar Cylinder



Inside


Note: Notch on cylinder must be in the 9 o'clock position when fully screwed into lock body.

3. Tighten Drive Bar Cylinder




Tighten locking screw to engage notch on cylinder

4. Mount Inside/Outside Plates




Align Passage/Privacy Button with Thumb-Turn spindle and secure trim plates to door.

5. Install Trim Plate



6. Install Door Jamb




Drill two 7/64" pilot holes

See template for door jamb prep specifications


1. Install Lock Body

2. Install Drive Bar Cylinder


3. Tighten Drive Bar Cylinder



See template for door prep specifications




Note: Notch on cylinder must be in the 9 o'clock position when fully screwed into lock body.



Tighten locking screw to engage notch on cylinder



4. Mount Inside/Outside Plates



Align Passage/Privacy Button with Thumb-Turn spindle and secure trim plates to door.

5. Install Trim Plate

6. Install Door Jamb



See template for door jamb prep specifications