



SPORTS HELMET FITTING GUIDE

IMPORTANT!

PLEASE READ THIS FITTING GUIDE BEFORE ALLOWING YOUR CHILD TO USE THEIR HELMET!

- 1** This helmet can only protect if it fits well. The potential wearer should try different sizes and choose the size which feels to them most secure and comfortable on the head.
- 2** This helmet should be adjusted to fit the wearer, e.g. the straps positioned so that they do not cover the ears, the buckle positioned away from the jawbone and the strap and buckle adjusted to be both comfortable and firm.
- 3** This helmet should be positioned on the head to ensure the intended protection is provided (e.g. that it should be placed so as to protect the forehead and not be pushed too far over the back of the head).

IMPORTANT!

- 4 This helmet cannot always protect against injury. Even wearing it, it is important to engage safely in your activity.
- 5 If this helmet is subjected to a severe impact, it should be discarded and destroyed.
- 6 It is dangerous to modify or remove any of the original component parts of this helmet other than as recommended by the manufacturer.
- 7 This helmet should not be adapted for the purpose of fitting accessories in a way not recommended by the manufacturer.



Note: Illustrations are for demonstration purposes only and may not reflect exact appearance of product.




**YOU'RE 3 STEPS
AWAY FROM SAFE
ADVENTURES!**





STEP 1

ADJUST THE REAR STRAP




TO TIGHTEN:

- 1 Turn the rear brace wheel clockwise to tighten.
- 2 When you do, the teeth strap will push outwards.




TO LOOSEN:

- 1 Turn the rear brace wheel counter-clockwise to loosen.
- 2 When you do, the teeth strap will pull inwards.




STEP 2

ADJUST THE CHIN STRAP



1 Grab the chin strap fork buckle on either side.

2 Grab both pieces of the strap end coming out from the fork.



3 Pull on the strap to tighten the chin strap.


4 To loosen, pull the strap on the other side of the buckle.






STEP 3

LOCK THE CHIN STRAP



- 1 Grab the strap fork with both fingers of one hand.
- 2 Grab the strap fork clamp with both fingers of one hand.

- 3 Push both pieces together, the fork into the clamp.
- !** Attempt to pull apart to check correct locking.





3Style
Scooters

PROBLEM? CONTACT US

hello@3style.co.uk

CONNECT WITH US!



VISIT 3STYLE.CO.UK

3Style Scooters,
Unit 30 Broomfield House,
Lanswood Park, Elmstead Market
Colchester, Essex C04 5WY, UK.

Company Registration No: 14219459

