



Humelle

Smart Humidifier

Model: AH1



User Manual

APPLE HOME (THREAD) SETUP




Make sure you have one of the Thread-enabled Apple Home Hubs already setup.

- HomePod 2nd Gen
- HomePod mini
- Apple TV 4K 2nd Gen
- Apple TV 4K 3rd Gen (Wi-Fi + Ethernet)



Download the Sleekpoint App from the Apple App Store, open it and create an account, or open the Apple Home App.

Make sure your iOS device is close to your accessory (less than 3m/10ft. away) and Bluetooth is turned on in your iPhone settings. Make sure one of your Apple Home Hub is close to your accessory (less than 10m/30ft. away).



Simultaneously press and hold Power and Light Buttons for approx. 5s to enter pairing mode untill you hear a long beep.

Add the accessory to the app following the on-screen instructions. As soon as it is added successfully, it will automatically connect to your Thread network. 5

\land Important Notice

When an accessory is added successfully for the FIRST TIME, it usually takes approx. 5-10 minutes to be able to connect to the Thread network. However, if it is still not able to connect to Thread after a while, reboot your iOS device or your Apple Home Hub and then check again.



USER MANUAL



CUSTOMER SUPPORT

If you have any questions or concerns about your new product, please feel free to contact our Customer Service Team.



Hello!

Thank you for choosing Humelle, our latest innovative product designed to optimize the humidity levels in your home, while providing a customizable and visually appealing atmosphere with its smart ring light feature. With its advanced sensors, Humelle can detect the current humidity levels in your home and adjust its output accordingly to maintain a target humidity level of your choosing. This helps to prevent dry air, which can lead to issues like dry skin, coughs, and other respiratory problems.

Humelle works seamlessly with Apple Home using Thread Technology. With a Thread-enabled Border Router (HomePod [mini] or Apple TV 4K), it allows for easy integration with your existing Apple Home setup, giving your the ability to monitor the humidity level in real-time, and control your Humelle with your iOS devices and through Siri voice commands from anytime, at anywhere.

For now, please be sure to explore all of its features outlined in this manual. If you have any questions, feel free to just drop us an email anytime. We'd love to assist you to get the most out of it!



IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ AND SAVE ALL INSTRUCTIONS TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS HUMIDIFIER. IF THE POWER ADAPTER OR UNIT DOES NOT WORK, CONTACT AIRVERSA CUSTOMER

SERVICE IMMEDIATELY.

When using electrical products, especially when children are present, basic safety precautions should Always be followed to reduce the risk of fire, electric shock, or other injury.

▲ ATTENTION

- **ONLY** use the humidifier as described in this manual.
- It is advisable to carry filled Water Tank with two hands.
- Humidifier requires regular cleaning. It is suggested to clean the humidifier every 72 hours.
- Place the humidifier and cord so that it will not be knocked over.
 DO NOT place near large pieces of furniture or in high-traffic areas.
- When not in use, turn the humidifier off and disconnect from power by removing the plug from the outlet.
- Keep the humidifier out of reach from children.
- **ONLY** fill the Water Tank with distilled, demineralized or purified water. Tap water can contain minerals that can create buildup in your humidifier, leading to bacteria growth and potential health hazards. Never fill the Water Tank with any other liquids.
- Remove the Water Tank from the base before moving the humidifier.
- If the humidifier is damaged or is not functioning properly, stop using it and contact **Customer Support** immediately.

- This humidifier is not to be used by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Supervise children when they are near the humidifier.
- Children should not clean or perform maintenance on the humidifier without supervision.
- Children should be supervised to ensure that they **DO NOT** play with the humidifier.
- Not for commercial use. Household and Indoor use only.
- Before using the humidifier, extend the cord and inspect for any signs of damage. If the power supply cord is damaged, please contact customer support for replacement in order to avoid an electric or fire hazard.
- Unplugging the power adapter will disable remote control of the humidifier and temporarily disconnect the humidifier from apps.
- ONLY add essential oils to the aroma box.

≜ MUST DOs


- Always have water in the Water Tank when operating the unit.
- Always unplug your humidifier from the power outlet before cleaning your humidifier or detaching the Water Tank from the humidifier base.
- Always make sure to place the humidifier on a flat, Level and waterproof surface away from sunlight before operation.
- Always make sure to place the humidifier at least three feet (1.2m) away from bedside, 12 inches (30cm) from the wall.

- **DO NOT** move or tilt humidifier while it is in operation.
- **DO NOT** use the humidifier in wet environments.
- DO NOT use hot water.
- DO NOT add essential oils or other substances to the Water Tank in the humidifier.
- DO NOT place the humidifier near sources of heat, such as stovetops, ovens, or radiators.
- DO NOT place the humidifier directly on floors, carpets, or rugs.
- DO NOT use other items as replacement parts for this product.
- **DO NOT** cover any openings on the unit or insert objects into any openings while the humidifier is on. Doing so may damage the humidifier.
- **DO NOT** use the unit if the cord has been damaged.
- DO NOT operate with power cord coiled or with twist tie in place.
- **DO NOT** operate the humidifier without water. Turn off and unplug unit when tank is empty.
- DO NOT immerse the humidifier base, power cord, or plug in water.
- **DO NOT** handle the power cord or plug with wet hands. Keep the plug and power cord away from liquids.
- DO NOT touch the Nebulizer while the unit is plugged in, as burns could result
- **DO NOT** add essential oils, medication, supplemental water treatment liquids, or water filters into the Water Tank or Base Water Chamber. This will damage the humidifier and cause leaks.

- **DO NOT** fill the humidifier with hot or boiling water. Use cool or lukewarm water to avoid the risk of burns.
- **DO NOT** let the water in the humidifier sit for extended periods of time. This can lead to bacteria growth and potential health hazards.
- **DO NOT** over-humidify your home. Keeping the humidity levels too high for an extended period of time can lead to mold growth and damage to your home's structure.
- **DO NOT** leave the humidifier unattended in a closed room. Doing so may result in personal injury or property damage. If room becomes saturated, open the door and turn the humidifier off or down.
- **DO NOT** use a detergent to clean any parts of the unit that contain water. Detergent film dissolved in the water supply can interfere with the output of the unit. Instead, Always use white vinegar mixed with water to clean the humidifier.
- **DO NOT** attempt to repair or adjust any electrical or mechanical functions on this humidifier. Doing so will void your warranty.
- **DO NOT** use the humidifier when an air purifier with a built-in air quality sensor, or an air quality sensor, is nearby. The water particles can mislead the air quality readings in the sensors, and could also possibly damage the sensor.

SAVE THESE IMPORTANT INSTRUCTIONS FOR EASY REFERENCE.

WHAT'S IN THE BOX



Humelle Smart Humidifier





*The image shown here is indicative only. If there is inconsistency between the image and the actual product, the actual product shall govern.

*The plug type of the power adapter varies depending on the region where this device is purchased.


HOW IT WORKS

Water is released from the Water Tank into the Base Water Chamber. A Nebulizer vibrates at ultrasonic frequency, breaking the water into a fine mist. The mist is quietly propelled by a fan up a vertical Mist Tube to the Mist Nozzle where the cool, visible mist enters the room. This humidifier will automatically shut off when the water level is low or when the Water Tank is removed from the Base.





CONTROL CENTER





Factory Reset:

Simultaneously press and hold Power and Light Buttons for approx. 5s to factory reset until you hear a long beep. DO NOT lift your fingers until you hear the beep.


SPECIFICATIONS

Model Name	AH1
Rated Input Voltage	100-240 V
Frequency	50/60 Hz
Water Tank Capacity	5.5L Approx. 1.5 gallons
Max Mist Output	330 ± 20 ml/h
Maximum Runtime	Up to 60 hours
Effective Room Size	50 m² 540 sq.ft.
Wireless Protocol	Thread
Bluetooth	BLE 5.2
Dimensions	9.1 x 9.1 x 10.4 in 23 x 23 x 26.5 cm
Weight	1.85 kg 4.08 lb


SLEEKPOINT APP




SETTING UP YOUR HUMELLE



Remove all packaging materials. Remove twist tie from power cord and extend power cord to full length.




Make sure Water Cap is secured in place. Clean the Water Tank with clean water before first use.



Place on a firm, level, water resistant surface a minimum of 12" (30cm) from any walls. Adjust the nozzle Mist should be directed away from any walls, bedding and furniture.


FILLING/REFILLING



ALWAYS unplug the humidifier before removing the Water Tank.



Remove the nozzle, use the handle to remove Water Tank from the base and turn upside down. Remove Water Tank Cap by turning counterclockwise (left).




Fill Tank with cool water. **DO NOT** fill with warm or hot water.



Lock Water Tank Cap by turning clockwise (right).

5

Place Tank on Base. The triangle arrow marks on the side should perfectly align with each other when placement is correct. Water will drain from the Tank into the Base Water Chamber when the Plunger is engaged.



Hard Water and White Dust:

- 1. High mineral content in your water, also known as hard water, may cause a white mineral residue to accumulate on surfaces in the room near the humidifier. This mineral residue is commonly referred to as white dust. The higher the mineral content (hardness) of your water, the greater the potential that an ultrasonic humidifier may produce white dust.
- **2.** White dust is not a result of a defect or flaw in the humidifier. It is a result of the amount of minerals suspended.
- Only fill the Water Tank with distilled, demineralized, or purified water. Tap water can contain minerals that can create buildup in your humidifier, leading to bacteria growth and potential health hazards. Never fill the Water Tank with any other liquids.
- Do not add water directly into the Water Base Chamber.
- Do not add essential oils into the humidifier. Only add essential oils to the aroma pad.


USING YOUR HUMIDIFIER

Plug in the humidifier. The power indicator on the display will light up along with a long beep. If there is no water in the tank, you will hear multiple short beeps.



Warnings:

Position humidifier to direct mist output away from walls, furniture and bedding.



Warnings:

Direct the nozzles away from any furniture, walls, or other objects to prevent them from getting wet. **DO NOT** inhale the mist directly from the nozzles.


Light Button


Tap:

- Turn the ring light on
- Cycle through favorite lighting themes

Press & hold:

• Turn the ring light off






Comfortable Humidity

A comfortable humidity level is between 40-60%. You may check real-time humidity and temperature level in the Sleekpoint app/Apple Home app.

Auto Target Humidity:

You may also set a target humidity level in-app to maintain your comfortable level of room humidity. Our algorithm automatically calculates the level of mist needed to maintain such target. For example, when humidity drops below target, the mist level will increase until the target humidty level has been reached. When humidity exceeds target, the humidification will decrease or pause until it falls back to target.




CONDENSATION:

If you notice condensation on the walls, windows or around the humidifier, the humidity level is too high. Open doors to the room or turn off humidifier until humidity level drops.

Using the essential oil tray

This humidifier features an Essential Oil Tray that can be used with your favorite essential oil for added enjoyment. This is not a diffuser - the oil does not come in contact with water and is passively evaporated into the air. Essential oils are not included.





DO NOT pour any liquids into the mist outlet.

DO NOT add liquid inhalants, essential oils or any additives to the water tank nor the Base Water Chamber. Doing so can have adverse effects on the humidifier and void the warranty.

CLEANING YOUR HUMIDIFIER

- To keep your humidifier running efficiently, you should clean your humidifier Water Tank and Base Water Chamber every 3 days, and when you're ready to store it.
 DO NOT store with water inside the Water Tank. Pack unit in original carton and store in a cool, dry location.
- All maintenance should be done in the kitchen or bathroom on a water-resistant surface near a faucet.
- Changing the water daily is highly recommended to avoid bacteria growth.
- Use a tissue or cloth to clean the nozzles regularly.
- Never immerse the base in water or liquid. DOING SO WILL DAMAGE THE HUMIDIFIER AND VOID THE WARRANTY.

Clean the water tank every three days 72 h

Outlet

Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.

Warning:

Do not place any part of the base in a dishwasher.



DO NOT pour any

water into the Air



Do not use detergents

to clean the humidifier.

Before Cleaning

- 1. Unplug humidifier. Never clean the humidifier when it is operating.
- 2. Remove Water Tank and empty completely from the Water Tank and Base.
- 3. Remove any accessories from the Water Tank and Base:







Water Tank Cap



\cap	

Mist Nozzle

Noise Silencer

Water Level Sensor

Essential Oil Tray

Cleaning Accessories

- Rinse all accessories with clean water.
- Dry all accessories with a cloth. Make sure all accessories are completely dry before reassembling or storing.

Cleaning the Essential Oil Tray





To clean the Essential Oil Tray, gently wipe residue from the Tray.

The Aroma Pad can be cleaned and reused after diffusing essential oils.

Cleaning the Nebulizer



Use a soft cloth or the included Cleaning Brush to gently clean Nebulizer, and all areas in Base Water Chamber.



Warnings: Nebulizer is fragile. **DO NOT** apply extreme pressure.

TROUBLESHOOTING

Mist leaks from the base Little mist or no mist is produced	 If Water Tank is empty, fill Water Tank with only distilled, demineralized or purified water. Make sure the water tank is properly in place. Make sure the plunger works properly. Plug the humidifier and tap Mist Button to turn the mist on. Mist light should be on. Make sure the air inlets are not blocked. Make sure the nebulizer is clean. If not, use Cleaning Brush to clean it. When the humidifier is operating in Auto-Mist mode, the mist will pause as soon as the target humidity is reached.
No power light	Plug the humidifier in
Humidifier is leaking	 Check for cracks on Water Tank and Base. Make sure Water Tank Cap is tightened. Make sure to place the humidifier on a flat, Level surface. Wipe excess water off Water Tank, top and bottom of Base. Do NOT shake the humidifier.
Humidifier makes a loud or unusual noise	 Make sure Water Tank is properly placed onto Base. The humidifier may be malfunctioning. Stop using the humidifier and contact Customer Support (see back cover).

Humidifier produces an unusual smell	 Clean the humidifier. Clean Aroma Pad & Essential Oil Tray.
Condensation forms around humidifier or on windows	 Decrease mist output to low setting open door/window to the room. Wipe excess water off Water Tank, top and bottom of Base.
White dust settling on surfaces in room	Replace tap water with distilled, demineralized, or purified water to minimize white dust.
The humidity level isn't changing in my room	 Use a higher mist level setting. Depending on your environment, the humidifier may take longer to humidify your air. The room may be larger than the humidifier's effective range. If the room is larger than 50 m², the humidifier will not be as effective.

NOTE:

Failure to keep this unit clean from mineral deposits normally contained in any water supply will affect the efficiency of operation of this unit. Customer failure to follow these instructions may void the warranty.



If you need further assistance, please feel free to contact us via support@airversa.com

WARRANTY

Sleekpoint Innovations Co., Ltd. (Sleekpoint) warrants this product to the original purchaser to be free from defects in material and workmanship, under normal use and conditions, for a period of 1 year from the date of original purchase.

Sleekpoint agrees, at our option during the warranty period, to repair any defect in material or workmanship or furnish an equal product in exchange without charge, subject to verification of the defect or malfunction and proof of the date of purchase.

There is no other express warranty.

This warranty does not apply:

- If the product has been modified from its original condition;
- If the product has not been used in accordance with directions and instructions in the user manual;
- To damages or defects caused by accident, abuse, misuse or improper or inadequate maintenance;
- To damages or defects caused by service or repair of the product performed by an unauthorized service provider or by anyone other than Airversa;
- To damages or defects occurring during commercial use, rental use, or any use for which the product is not intended;
- To damages or defects exceeding the cost of the product.

Sleekpoint will not be liable for indirect, incidental, or consequential damages in connection with the use of the product covered by this warranty.

This warranty extends only to the original consumer purchaser of the product and is not transferable to any subsequent owner of the product regardless of whether the product is transferred during the specified term of the warranty.

This warranty does not extend to products purchased from unauthorized sellers. Sleekpoint's warranty extends only to products purchased from authorized sellers that are subject to Sleekpoint's quality controls and have agreed to follow its quality controls.

All implied warranties are limited to the period of this limited warranty.

If you discover that your product is defective within the specified warranty period, please contact Customer Support via support@airversa.com. DO NOT dispose of your product before contacting us. Once our Customer Service Team has approved your request, please return the product with a copy of the invoice and order ID.



FCC WARNNINGS

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning:

Changes or modifications made to this device not expressly approved by Shenzhen Rundian Innovation Technology Co. Ltd. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Contains FCC ID: 2ALGY-22066