

# CHEST FREEZER

BD/BC-74D

PRODUCT USE GUIDE

# TABLE OF CONTENTS

---

## INTRODUCTION

Thank you for choosing a LIFEPLUS chest freezer.  
This owner's manual will provide you with valuable  
information necessary for the proper care and  
maintenance of your new product.  
Please take a few minutes to read it

SECTION 1	
IMPORTANT NOTE	PAGES 3-4
SECTION 2	
TECHNICAL PARAMETERS & PACKAGE INCLUDE	PAGES 5
PRODUCT INTRODUCTION	PAGES 6
SECTION 3	
PRECAUTIONS BEFORE USING	PAGES 7
SECTION 4	
USE OPERATION	PAGES 8
SECTION 5	
TROUBLESHOOTING GUIDE	PAGES 9
SECTION 6	
NORMAL PHENOMENA	PAGES 10
SECTION 7	
MAINTENANCE GUIDELINES	PAGES 11
SECTION 8	
WARRANTY	PAGES 11

---

## IMPORTANT NOTE


- (1). A fitting one-phase alternating power must be supplied to the unit. If there is a big fluctuation in the voltage, please be assisted with a power regulator otherwise it would be affected the operating even burn out the compressor.
- (2). A single-phase socket and suitable fuse are allowed for the unit only. Do not use the multifunction socket which may cause a fire or electrical shock.
- (3). The broken power wire must be changed by the manufacturer's maintenance personnel or a similar department.
- (4). Be sure to ground the unit.
- (5). If the unit is unplugged, power is lost, or turned off, it needs to wait for five minutes before restarting the unit.
- (6). Never install the unit at an inflammable and volatile location and never install the unit at a place of acid or corrosive gas which may cause an explosion or fire.
- (7). Never splash water outside or inside of the unit as this may cause electrical shock or short circuit.
- (8). Never store volatile, flammable, or corrosive material in the unit.
- (9). Never store medicine or other medical products. Please contact us if storing this kind of products.
- (10). Handling the frozen contents with naked hands may cause frostbite.
- (11). Do not damage the power cord to avoid the electric leakage or fire.
- (12). Make sure to keep the key in a safe place where the children cannot reach. Do not permit children to play around the unit as danger may result.
- (13). Do not break the loop of the cooling system.
- (14). Do not put any other electrical equipment in the food closet of the freezer.
- (15). Do not use mechanical devices or other means to accelerate the defrosting process other than those recommended by the manufacturer.
- (16). The damaged lamp must be replaced with the same model as the original by the maintenance and warranty department of the producer or by similar professional and authorized technicians.

- (17). This appliance is not intended for use by persons including children with reduced physical, sensory, or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. The children should be supervised to ensure that they do not play with the appliance.
- (18). Don't use electric products in the food storeroom of this product.
- (19). This appliance is intended to be used in households and similar applications such as
  - staff kitchen areas in shops, offices, and other working environments;
  - farmhouses and clients in hotels, motels, and other residential-type environments;
  - bed and breakfast type environments;
  - catering and similar non-retail applications.
- (20). Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.


# TECHNICAL PARAMETERS

Model No.	BD / BC-74D
Item Name	Chest Freezer
Rated Voltage	115V
Rated Power	58W
Freezing Temperature	-7.6°F to 21.2°F (-22°C to -6°C)
Energy Consumption	0.37 kWh / 24h
Package Weight	39.68lbs
Package Size	18.5x22.4x29.3inch


# PACKAGE INCLUDE



1X Chest Freezer




1X Plastic Basket



1X Owner's Manual

Please check whether the accessories in the above picture are complete. If the freezer is damaged or incomplete during transportation, please contact the seller immediately.

# PRODUCT INTRODUCTION



## PRECAUTIONS BEFORE USE

### Portage and Placement

1. To avoid any trouble from the compressor or the system, the inclination of the unit can't be over 45° during transportation.
2. Place the appliance away from direct sunlight and sources of heat from the stove, heater, radiator, etc. Direct sunlight may affect the acrylic coating and the heat sources will increase the electrical consumption.
3. Remove the exterior and interior packing before using. It is necessary and recommended to keep at least 100mm of space away from the back and sides of the unit and it can allow the proper air circulation to cool down the compressor.

### Preparation


\*After receiving the freezer or moving the freezer for a long distance, please let the machine stand for 24 hours before turning it on again.

1. Be sure to ground the unit and the grounding can prevent the electrical shock which would occur when the electrical insulation of the unit becomes insufficient.
2. Connect the unit to the power supply with the rated frequency and rated voltage indicated on the rating label. Please use the input power regulator upon 5 times alternating power if the voltage is much more fluctuant than normal.
3. Use the specified power socket and suitable fuse.
4. Hold the power supply plug, not the cord when pulling out the power cord from the socket.
5. Never splash the water on the unit directly. The wet unit may cause an electric shock or short circuit.
6. Turn on the power five minutes later after the power is off or stops running to protect the system and the compressor.
7. If the power supply cord needs to be extended, the connected cord area should be more than 0.824mm<sup>2</sup> and the cord is composed of one or more wires. Don't be connected to the multifunctional power supply socket.
8. Turn on the power and switch the temperature control knob to the 3-4 position. Check the indicator light, compressor, and ventilating fan after half an hour. The temperature inside will cool down obviously and it means the unit working normally.

## USE OPERATION

### Temperature Control and Adjustment

1. The internal temperature can be adjusted by temperature control. The higher the figure means the lower the temperature. The normal position is between 3 and 4.
2. The " 1 " knob refers to the refrigeration point, and the storage temperature in the cabinet is about 10.2°F. When you need to freeze food quickly, turn the knob clockwise to " 7 ". At this time, the compressor will work continuously. After freezing, turn the knob counterclockwise back to its original position. Do not turn the temperature control knob clockwise from " 7 " to " 1 ".



### Food Storage and Quick-freezing

1. Do not put large amounts of food into the unit at one time.
2. Let the compressor run for 2 to 3 hours for the first operation.
3. Warm food must be cooled down to normal temperature before being put into the unit.
4. Make sure that there is enough space around food.
5. Keep the food in the same or similar sort area.
6. Do not put glass bottles and cans whose freezing point is higher than compartment temperature into the unit since they may be broken by frozen contents and cause injury.

### Defrost

1. Do not use the sharp or metal piece to scrape the frost when defrosting. It needs to turn off the power and open the doors for defrosting naturally.
2. Dry and clean the unit with a soft cloth after defrosting.

## TROUBLESHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE
The unit does not operate.	<ul style="list-style-type: none"> <li>● Not plugged in.</li> <li>● The circuit breaker tripped or blown fuse.</li> <li>● The temperature control is set too warm.</li> </ul>
The unit is not cold enough	<ul style="list-style-type: none"> <li>● Make sure that the temperature control is set to an appropriate value.</li> <li>● The external environment may need to set a lower value.</li> <li>● The door is often opened.</li> <li>● The door is not completely closed.</li> <li>● The door gasket is not properly sealed.</li> <li>● The machine does not have the correct gap.</li> </ul>
The compressor turns on and off frequently	<ul style="list-style-type: none"> <li>● The room temperature is higher than normal.</li> <li>● Too much food has been put in the machine.</li> <li>● The door is often opened.</li> <li>● The door is not completely closed.</li> <li>● The temperature control setting is incorrect.</li> <li>● The door gasket is not properly sealed.</li> <li>● The machine does not have the correct gap. ap.</li> </ul>
Vibrations	<ul style="list-style-type: none"> <li>● Check to ensure that the unit is level.</li> </ul>
The unit seems to make too much noise	<ul style="list-style-type: none"> <li>● The rattling noises may come from normal refrigerant flow.</li> <li>● At the end of each cycle, you may hear a gurgling noise due to refrigerant flowing through the equipment.</li> <li>● The contraction of the inner wall may cause crackling and popping noises.</li> <li>● The freezer is not placed horizontally.</li> </ul>
The door will not close properly	<ul style="list-style-type: none"> <li>● The unit is not level.</li> <li>● The gasket is dirty.</li> <li>● The shelves are out of position.</li> </ul>

## NORMAL PHENOMENA

1. If hearing the sound of water flowing in the unit, this is the refrigerant flowing sound inside the pipe.
2. If there is some dew on the surface of the unit, please wipe it with a dry cloth
3. The temperature on the compressor surface can reach about 70 °C - 90 °C during its working time.

## MAINTENANCE GUIDELINES

1. Use the neutral detergent to wipe off the dirt on the surface of the unit then dry and clean the unit with a soft cloth.
2. Use the dust collector to wipe off the dirt on the condenser to keep it in a good condensing condition.
3. Rubbing some talcum powder on the door gasket can prolong its life.



### Correct disposal of this product

1. This marking shown on the product or its literature indicates that it should not be disposed of with other household wastes at the end of its working life. To prevent any possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources.
2. Household users should contact either the retailer where purchasing this product from or their local government office for details of where and how they can take this item for environmentally safe recycling.
3. Business users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

## WARRANTY

After-sales Service Letter of Commitment:

All products purchased in our company are guaranteed to keep in good repair for 1 year. If quality problems happen in the guarantee period, our company will maintain them for free or provide a replacement. Additionally, our company provides technical support and fittings for life. After-sales service isn't restricted by time and hearing feedback and ideas of users and dealing with them in time. If you are caught in some problems when using our products, welcome to contact us at any time.

Warning: Risk of fire / flammable materials, taking care to avoid causing a fire by igniting flammable material.

- WARNING: Keep ventilation openings, in the appliance enclosure or the built-in structure, clear of obstruction.
- WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

## DEFROSTING

When 5mm frost forms in the freezer, please shave it and throw it away.

If you defrost completely, please do it as follows:

1. Please make the inside empty. And disconnect the power cord plug.
2. When frost starts thawing, please shave it and you will be able to defrost in the short time
3. After draining, please wipe the inside, and put a rubber cap on the drain bolt and inside drain.

For defrosting the chest freezer, don't use a hammer, knife, or bolt. If you use it, it gives damage to the inside evaporator.

And chest freezer cannot cool, and inside goods can thaw.

Please do not destroy the freeze loop

Please do not store anything other than the manufacturer's recommendation.



### WARNING



## SAFETY PRECAUTIONS 1

- To ensure proper use. Please thoroughly study these SAFETY PRECAUTIONS before operating the Unito
- The purpose of the safety precautions in this manual is to ensure the safe and correct use of the unit to minimize risks that could cause serious damage and injury to you or other persons. The safety precautions are divided into WARNINGS and CAUTIONS. Cases, where improper handling of the unit could lead to death or serious injury, are listed under the warning heading. However, the cases adhere strictly to both types of safety precautions



**WARNING** Improper handling of the unit could lead to death or serious injury





**CAUTION** Improper handling of the unit could lead to serious results depending on the circumstances.

- Text set off by the exclamation mark  contains information that should be strictly adhered to.

After reading the instruction manual, store the easily accessible place where the user ( s ) of this product can easily find it.

### ◆ PRECAUTIONS FOR INSTALLATION

## WARNING

-  Installation should be performed only by the dealer or a qualified expert
-  Attempting to install the unit yourself could result in water leakage, refrigerant leakage, electrical shock, or fire.



**WARNING:** Do not splash water directly onto the cooler and do not wash with water.

Short-circuit and electrical shock could result.