
Rectangular panel LED light and stand-off plywood installation




Blue Grouse Wine Cellars



Rectangular panel LED light and stand-off plywood installation

Step 1

Install pre-cut plywood panel, use a level to ensure level installation
Plywood should be screwed to wall studs or using appropriate anchors/screws



Step 2


Cut LED channels to size and glue to 4 plywood edges using instant glue or double sided tape

PG. 2 of 4 (installation)

Blue Grouse Wine Cellars




Rectangular panel LED light and stand-off plywood installation



Step 3

Connect wire lead to LED driver's wires, LED strips come with adhesive, glue carefully all around the bottom of channels in a continuous run



Step 4

Cut clear diffusers to size and snap into installed channels

Step 5


Install VINdustry rectangular peg panel (Follow peg panel's installation instructions)

PG. 3 of 4 (installation)

Blue Grouse Wine Cellars



Rectangular panel LED light and stand-off plywood installation



Blue Grouse Wine Cellars

