



# Chemical Consultants INCORPORATED

## Eco-Strip®A

(APEO / NPEO FREE)

Multi-Purpose Screen Wash

### GENERAL DESCRIPTION

Eco-Strip®A is water soluble ink degradant. It is highly effective on plastisol, multipurpose (solvent based), and UV inks. Eco-Strip®A can also be diluted with water. This makes it ideal for use with water-base ink systems. Eco-Strip®A will protect the fabric from deep stains or ghosting from the image print. This makes it much easier when complete reclamation of the screen is necessary.

Eco-Strip®A can be used in a wide variety of innovative cleaning processes ranging from re-circulation machines, dip tanks, immersion cleaning processes, and automatic reclaiming machines. It can also be applied manually with a scrub pad, spray bottle, or pneumatic pump systems.


Eco-Strip®A is also an excellent plastisol ink haze (ghost) remover. It is non hazardous (noncorrosive) and aggressively removes image stains from the mesh.

### ADVANTAGES

- Easy to use
- Economical - Can be diluted with water
- Reduces labor
- Low Odor
- Low Foam
- Low-VOC (volatile organic compounds) : after dilution with water
- High Solvency: immediately breaks down ink
- High Flash Point / Non-Flammable
- Non-Hazardous
- High load capacity to reduce usage
- Safe on all types of mesh
- Biodegradable / Drain Safe
- Ideal for use in automatic reclaiming equipment
- Multiple applications
- Does NOT Contain Alkylphenol Ethoxylates (APEO) / Nonylphenol Ethoxylates (NPEO)

### APPLICATIONS

Always card excessive ink from screen. Use one of the following applications.



#### INK WASH-OUT AT THE SINK:

Card excessive ink from the screen. Apply Eco-Strip®A to ink side of screen. Use a non-abrasive scrub brush or pad to agitate ink on both sides of screen. Finally, rinse away all residue away using high pressure water.

#### Packaging

1 gallon    5 gallon pail    55 gallon drum

#### Haze Remover:

After ink and emulsion has been removed, spray Eco-Strip®A on both sides of the screen. Scrub screen both sides with a non-abrasive brush or pad. Allow product to dwell a few minutes (depending on severity of stain). High pressure rinse screen working from bottom and moving upwards.



#### SQ-1000 Squeegee Cleaner

[Click here for more details.](#)



#### RECIRCULATING WASH:

Card excessive ink from the screen. This product can be continuously recirculated until product becomes too heavily soiled with solids. Used product may be filtered and reused.

#### Quick Tip:

Always pressure wash screen from the bottom and work upwards.

This will prevent ink from locking back onto the mesh when coming in contact with the rinse water.