

# Dip Powder

*Follow the step-By-Step Guide*

## *PREP*

1

Prep nails by pushing back cuticles with 14 Day Mani nipper and pusher.

2

Buff the nails with a 14 Day Mani nail file or white buffer block.

3

Dehydrate nails with 2 pumps of acetone on a 14 Day Mani Lint free wipe. This removes any grease from the nails.

## *APPLY*

4

Apply a thin layer of pro base to the entire natural nail.

5

Dip your nail into desired 14 Day Mani dip powder at a 45degree angle.

6

Leave your finger for 2-5 seconds. Remove and dust off excess with a powder brush.

7

Repeat steps 4, 5 & 6 2-3 more times.



Scan the code to view our step by step video