GHOST WATCH_{1.0} TEMPUS

Model: WTC 1.0 User Manual

Display and Button Functions



Key S1: Start/Stop/Turn On&Off/Up

Key S2: Reset/Down

Key S3: Mode/Confirm/Save


Key S4: Light/Set

Function Instruction

- 1. 12-digit display: Hours/Minutes/Seconds/Steps count/ Percentage of target steps; Month/date/year.
- 2.12/24 hour format.
- 3. Steps counting:
 - a, Personal parameter input settings.
 - b, Turn on or off pedometer manually. In pedometer mode, there are sleep and data clearing functions;
- Real-time query of the accumulated step data of the day: number of steps, calories, exercise mileage, exercise time.
- d, Historical pedometer data storage and query function, which can store 31-day pedometer data and query historical data every day: steps, calories, exercise mileage, exercise time.
- 4. Alarm: can set the alarm, hourly chime, snooze function.
- Stopwatch: Maximum stopwatch timing 23H:59M 59S.
- 6. The second time.
- 7. Countdown: the maximum countdown time is 24 hours.
- 8. Low voltage detection.
- 9. LED back-light, press S4 to turn on 3 seconds back light.

Backlight & Full display& Low battery detection

- 1. In any mode, press the S4 key to light up and delay for 3s.
- In any mode, press S1-S2-S3 keys in turn will full display; Press any key again to exit the full display and return to the current display.
- When the battery voltage is less than 2.4V, the low battery detection prompt icon will be displayed.



Month, Day, Week display

